

Modbus Configuration
Software
Modbus Tools



User Guide

HA028988

September 2011 (Issue 5)

© 2011

All rights are strictly reserved. No part of this document may be reproduced, modified, or transmitted in any form by any means, nor may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without prior written permission of the manufacturer.

The manufacturer pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. The manufacturer will not accept responsibility for any losses arising from errors in this document.

MODBUS Tools Help Manual

Table of Contents

1	MODBUS TOOLS.....	7
1.1	OVERVIEW OF MODBUS TOOLS.....	7
1.2	LIN INSTRUMENT MODBUS CAPABILITIES.....	8
1.2.1	Memory Size.....	8
1.2.2	Operating Mode.....	8
1.2.3	32-bit.....	8
1.2.4	2-bit Swapped.....	8
1.2.5	Tick Rate.....	8
1.2.6	Instrument Options.....	9
1.2.7	Interface Type.....	9
1.2.8	Number of Interfaces of each Type.....	9
1.2.9	CNOMO Registers.....	9
1.3	CONVENTIONS.....	9
1.4	STARTUP.....	9
2	VIEW.....	10
2.1	TOOL BAR.....	11
2.2	REPORT WINDOW.....	12
2.3	STATUS BAR.....	12
2.4	EDITING TECHNIQUES.....	13
2.4.1	Drop down menus.....	13
2.4.2	Text/Numeric Entry.....	13
2.4.3	Multiple editing.....	13
2.4.4	Multiple Item selection.....	13
3	PORT PROPERTIES TAB.....	14
3.1	FILES.....	15
3.1.1	File Name.....	15
3.1.2	Database.....	15
3.2	OPERATING MODE.....	15
3.2.1	Mode.....	15
3.2.2	Slave Addr:.....	15
3.2.3	Serial/TCP.....	16
3.2.4	TCP Properties (Devices tab).....	17
3.2.5	TCP Properties (Properties Tab).....	18
3.3	LINK SETTINGS.....	20
3.3.1	Serial Settings.....	20
3.3.2	Time out.....	20
3.3.3	Instrument Options.....	20
3.4	TICK RATES.....	23
3.5	GWF TABLES.....	24
3.6	GWF SIZE.....	24
3.7	AUTO CREATE TABLES.....	24
3.7.1	Diagnostic Table.....	25

3.7.2	CNOMO Response	25
4	REGISTER TAB.....	26
4.1	ADDING REGISTERS.....	27
4.1.1	Slave Addr.....	27
4.1.2	Inst. No.	27
4.1.3	Offset.....	28
4.1.4	Count.....	28
4.1.5	Format.....	28
4.1.6	DP.....	28
4.1.7	Read-Write.....	28
4.2	MOVING REGISTERS.....	29
4.2.1	Cut, Copy and Paste	29
4.3	UNMAPPED REGISTERS	30
4.4	COLUMN HEADINGS.....	30
4.4.1	Slave Addr.....	30
4.4.2	Instr No.....	30
4.4.3	Offset.....	30
4.4.4	Field.....	31
4.4.5	Format.....	32
4.4.6	Decimal Places	33
4.4.7	Read-Write.....	33
4.4.8	Table.....	34
4.4.9	Tick Rate.....	34
4.4.10	Description.....	34
4.4.11	Pinned	34
5	DIGITAL TAB.....	35
5.1	COLUMN HEADINGS.....	36
5.1.1	Width.....	36
6	DIAGNOSTIC TAB.....	37
6.1	REGISTERS 1 TO 16.....	38
6.2	REGISTERS 17 ONWARDS	38
6.2.1	Master Mode.....	39
6.2.2	Slave mode	40
6.3	DIAGNOSTIC FUNCTION CODES.....	41
6.4	EXCEPTION RESPONSES	41
7	TABLES TAB.....	42
7.1.1	Editing cells on the tables grid	42
7.1.2	Table Number	43
7.1.3	Table Type.....	43
7.1.4	Function Codes.....	43
8	MENU BAR.....	44
8.1	FILE MENU.....	45
8.1.1	New.....	45
8.1.2	Open.....	45
8.1.3	Save.....	45
8.1.4	Save As.....	46

8.1.5	Save Special	46
8.1.6	Import CSV	46
8.1.7	Export CSV	47
8.1.8	Page Setup	48
8.1.9	Print setup.....	48
8.1.10	Print Preview	48
8.1.11	Print	49
8.1.12	Previous configurations	49
8.1.13	Exit	49
8.2	EDIT MENU.....	50
8.2.1	Undo (last action)	50
8.2.2	Redo (last action).....	50
8.2.3	Cut.....	50
8.2.4	Copy	50
8.2.5	Paste	51
8.2.6	Paste Special.....	51
8.2.7	Delete.....	51
8.2.8	Goto.....	51
8.2.9	Add Registers	51
8.2.10	Add Table.....	51
8.2.11	Autocreate	52
8.3	VIEW MENU.....	53
8.4	HELP MENU	54
8.4.1	About	54
8.5	CONTEXT MENU	54
8.5.1	Undo (last action)	54
8.5.2	Redo (last action).....	55
8.5.3	Cut.....	55
8.5.4	Copy	55
8.5.5	Paste	55
8.5.6	Paste Special.....	55
8.5.7	Delete.....	55
8.5.8	Goto.....	56
8.5.9	Add Registers	56
8.5.10	Add Table.....	56
8.5.11	Autocreate	56
9	COMMAND LINE PARAMETERS.....	58
9.1	MDBTOOLS [/ <COMMAND>] <PATH> [/ CSVDELIMITER:] COMMAND LINE PARAMETER.....	58
9.1.1	Example	58
9.2	/ EDIT < PATH > COMMAND LINE PARAMETER	58
9.2.1	Example	58
9.3	/ CREATEGWF < PATH > COMMAND LINE PARAMETER	58
9.3.1	Example	58
9.4	/ CREATEUJG < PATH > COMMAND LINE PARAMETER	59
9.4.1	Example	59
9.5	/ CREATECSV < PATH > COMMAND LINE PARAMETER.....	59

9.5.1	Example	59
9.6	/CSVDELIMITER: COMMAND LINE PARAMETER.....	59
9.6.1	Example	59
9.7	/VALIDATE < PATH > COMMAND LINE PARAMETER.....	59
9.7.1	Example	59
9.8	/REGSERVER COMMAND LINE PARAMETER.....	59
9.8.1	Example	59
9.9	/UNREGSERVER COMMAND LINE PARAMETER.....	59
9.9.1	Example	59
10	OTHER ITEMS.....	60
10.1	32-BIT DATE AND TIME.....	60
10.1.1	POSIX format.....	60
10.1.2	ISO8601 format	60
10.2	CNOMO REGISTERS.....	61
11	INDEX.....	62

1 MODBUS TOOLS

Modbus Tools is a powerful multi-purpose Windows-based software package for use off-line.

It uses and outputs fully MS DOS-compatible files that can be saved locally to hard or floppy disk, or transferred to and from target instruments at high speed over the following communications medium.

LIN via PCLIN or PC cards

ELIN via an Ethernet port

ALIN via a PCALIN or Arcnet card

via a serial port (SLIN)

It is used to define the communication method between LIN and Modbus instruments, for example, Programmable Logic Computers (PLC's), and third-party supervisors.

1.1 OVERVIEW OF MODBUS TOOLS

Modbus Tools is used to define the communication between LIN and Modbus instruments, for example, Programmable Logic Controllers (PLC's), and third-party supervisors.

The Modbus configuration runs alongside a regular LIN Database, in a Project instrument environment provided with a Modbus interface, referred to as a *Gateway*. The Modbus configuration defines the communication between the LIN Database and the Modbus device. This enables the integration of devices external to the LIN, for example PLC's, and permits communication with third-party supervisors.

Note

Modbus Tools is part of a Project based suite of tools and can also be used to configure instruments operating within a single instrument environment.

Modbus Tools offers:

A common toolset for Modbus supported products.

Automatic documentation.

The LIN instrument may be configured either as a Master, communicating with one or more Modbus instruments, or as a slave.

The Modbus configuration data is defined in a source file (.ujg).

A Modbus GateWay file (.gwf) is generated and this is downloaded along with the LIN Database (.dbf) file into a LIN instrument. Some instruments support more than one Modbus Gateway facility, each can specify a unique Gateway file via a GW_CON block. Each GW_CON block specifies a Gateway file defining the communication parameters required to transfer data between the LIN Database and Modbus registers in instruments in this individual Gateway facility.

Note

An appropriate number of GW_TBL blocks can be added to a LIN Database if the features it contains are required to access the Modbus diagnostic data. The GW_TBL block is a more efficient way of accessing Modbus diagnostic data than via a table, and also has the advantage of releasing one table for the configuration. Configuring the GW_TBL block disables the corresponding diagnostic tables, thereby avoiding bit-value conflicts.

Refer to the LIN Blocks Reference Manual (Part no. HA082375U003), in Online Books, for full details.

1.1 OVERVIEW OF MODBUS TOOLS (Cont.)

This Modbus GateWay file data defines:

The operating mode (Modbus master or slave).

The communications link set-up (Serial or TCP).

The mapping between fields in LIN function blocks and the registers of a Modbus instrument.

How field values are transferred between instruments. For example which Modbus function codes to use, the addresses of Modbus registers and the format in which data is to be transferred.

1.2 LIN INSTRUMENT MODBUS CAPABILITIES

When a Modbus configuration is associated with a LIN Database, the instrument target library version is read from the database file to determine the LIN Instrument Modbus capabilities.

Note

Instruments that do not support instrument and communication parameter configuration by means of either on-screen menus or the Instrument Options tab on the Instrument Properties dialog can use an appropriate text editor, i.e. 'notepad.exe', to edit it.

The following is a summary of the capabilities that can be defined for each instrument type:

1.2.1 Memory Size

This is the memory available in the instrument for Modbus data to be downloaded to. This value is shown in the GWF Size - Max Size on the Port Properties tab.

Max Tables

This is the maximum number of tables supported by the instrument. This value is indicated by the GWF Tables - Max on the Port Properties tab.

1.2.2 Operating Mode

The Operating Mode can be changed, if the instrument type supports the selected, Master or Slave, operating mode on the Port Properties tab.

1.2.3 32-bit

The instrument type may support mapping of pairs of analogue registers to 32-bit IEEE format. If supported the 32-bit option is included in the Format selection on the Register tab.

1.2.4 2-bit Swapped

The instrument type may support mapping of pairs of analogue registers to 32-bit IEEE format Word Swapped with low word first. If supported the 32-bit - Swapped option is included in the Format selection on the Register tab.

1.2.5 Tick Rate

If supported then the Tick Rate options are enabled (in Master mode only). Values for Slow, Medium and Fast tick-rates are edited in the Port Properties tab Tick Rate. Slow, medium or fast Tick Rate can be selected in the Tables tab. In Slave mode the Tick Rate value remains read-only 'Default'.

In auto-create table mode, the tick-rate value for individual registers can be modified, but this affects the allocation of registers to tables.

1.2 LIN INSTRUMENT MODBUS CAPABILITIES (Cont.)

1.2.6 Instrument Options

For most instrument types, all instrument options are defined within the Modbus Tools and saved in the Modbus Gateway file, .gwf. For certain instrument types, the options are specified using the Instrument Options editor. These options include Slave Addr. (in Slave mode), Baud Rate, Parity, Stop Bits (in Serial mode) and Timeout.

1.2.7 Interface Type

The instrument type may support Serial (EIA232) and TCP interface types. The Instrument may support one or more port connections for the selected Interface Type.

1.2.8 Number of Interfaces of each Type

The instrument type may support one or more port connections for the selected Interface Type. If Serial is selected, the Serial Port setting (Serial Port: COMn) in the Operating Mode section shows the port used for Modbus Serial communications. If TCP is selected, the Serial Port setting changes to TCP port (TCP port: n) and shows the port used for TCP/IP communications.

1.2.9 CNOMO Registers

The instrument type may support Comité de Normalisation des Moyens de production (CNOMO) registers. The CNOMO registers return manufacturer and product detail values when the instrument is configured to operate in Modbus Slave mode only. It displays the Manufacturer's ID, Device type i.e. LIN identifier value, and Device version at pre-defined Offset values 121, 122, and 123 respectively in the Register tab.

Note

Offset value 124, will display the instrument status, Device heartbeat.

1.3 CONVENTIONS

Where specific computer keys have to be operated, this is signified as in the following example:

<Ctrl> + <C>

which means 'Hold the control key down whilst operating the C key'.

Some keyboards may have different key legends. <Delete> for example, may appear as .

1.4 STARTUP

Modbus Tools can be invoked by:

Double-clicking on a .ujg file in the LINtools project workspace view, or


Double-clicking on a .ujg file in a LIN instrument project folder.

Note

The Modbus Tools may also be started using Command Line Parameter statements.

2 VIEW

As shown in the figure below, Modbus Tools is presented as a single tabbed view with an error report window.



The tabs are named:

Port Properties

Register

Digital

Diagnostic

Tables


And are all described in separate topics.

2.1 TOOL BAR




Note:


The Toolbar can be displayed or hidden using the View menu 'Toolbar' item.

 **New.** This command is used to create a new Modbus configuration. The user is prompted to select a LIN database file to be referenced for LIN block field tag browsing.


The file menu command 'New' and the shortcut <Ctrl> + <N> can be used as alternatives.


 **Open.** This tool is used to open an existing Modbus configuration. If a LIN database file has not already been specified, the user is prompted to select a LIN database file to be referenced for LIN block field tag browsing.


The file menu command 'Open' and the shortcut <Ctrl> + <O> can be used as alternatives.


 **Save.** This command is used to save the active Modbus configuration to its current name and directory (folder). The first time a configuration is saved, the 'Save As' dialogue box appears to allow the configuration path name to be defined. The file menu command 'Save' and the shortcut <Ctrl> + <S> can be used as alternatives.


To save an already-saved configuration to a different path name, use the File menu 'Save As...' command.


 **Cut.** This deletes the highlighted registers from the configuration and places them on the clipboard for pasting elsewhere. The Edit (or right-click) menu command 'Cut' and the shortcut <Ctrl> + <X> can be used as alternatives.


 **Copy.** This copies the highlighted registers from the configuration and places them on the clipboard for pasting elsewhere. The original items remain in place. The Edit (or right-click) menu command 'Copy' and the shortcut <Ctrl> + <X> can be used as alternatives.


 **Paste.** Imports register data from the clipboard into the configuration. The Edit (or right-click) menu command 'Paste' and the shortcut <Ctrl> + <V> can be used as alternatives.


 **Paste special.** Imports register data from the clipboard into a new destination within the configuration. The Edit (or right-click) menu command 'Paste Special...' and the shortcut <Ctrl> + <Q> can be used as alternatives.


 **Undo.** This reverses up to the last six editing actions, if possible. The Edit (or right-click) menu command 'Undo' and the shortcut <Ctrl> + <Z> can be used as alternatives.


 **Redo.** This reverses the last 'Undo' action, if possible. The Edit (or right-click) menu command 'Redo' and the shortcut <Ctrl> + <Y> can be used as alternatives.


 **Print.** Initiates printing of the configuration, via the standard Printer Dialogue box, which allows the user to select the required printer, paper source, single/double sided etc.

 **Add registers.** Allows the user to add one or more registers to the table as described in 'Adding Registers'.

 **TCP Properties.** See the separate topic: TCP Properties. The View menu 'TCP Properties' item, or the shortcut <Ctrl> + <D> can be used as alternatives.

 **Open database.** Clicking on this toolbar icon opens the target database in LINtools.

 **Back.** This returns the user to the calling application. For example, if this instance of Modbus Tools has been launched from LINtools by double-clicking a Modbus file in the contents window, then clicking on this icon returns the focus to LINtools.

 **About.** Displays details about this version of Modbus tools. Also available from the Help menu 'About Mdb Tools...' item.

2.2 REPORT WINDOW

```
Error: Analogue register, slave 1, offset 100 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 101 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 102 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 104 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 106 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 107 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 108 - Offset: Duplicate register offset
Error: Analogue register, slave 1, offset 109 - Offset: Duplicate register offset
```

Located in the lower part of the display area, this window displays validation errors.

Registers or table data which fail the validation checks are displayed in Red.

Validation is carried out

When a .upg file is loaded

When a .upg file is saved

Whenever data is modified


Validation involves checking that the data is complete and that it is consistent with the LIN Database (.dbf) file - i.e. the referenced LIN fields exist in the .dbf file and are of the correct type.

Double clicking on an error causes the tabbed window to jump to the erroneous data.

The Report Window can be toggled on and off from the View menu, or by typing <Alt> and <V> simultaneously, then <R>.

2.3 STATUS BAR

The Status bar is to be found at the bottom of the display area. The status bar can be toggled on and off, using the View menu 'Status Bar' item, or by typing <Alt> and <V> simultaneously, then <S>.



The left hand area of the status bar contains tool tips information, giving a brief description of tool bar or menu commands whilst the cursor is hovering over them.

The right hand area contains details of the port properties mode (Mode: MASTER or Mode: SLAVE), Auto-create tables mode (AUTO create tables or MANUAL create tables) and the percentage of GWF memory that has been used so far.


The status of the computer keyboard lock keys (CAP, NUM and SCRL) is also displayed.


2.4 EDITING TECHNIQUES

2.4.1 Drop down menus

(Also known as ‘Combo’ menus.)

Drop down menus present the user with a number of fixed-value items to choose from. The required value is clicked on to select it, and the menu then closes.

Drop down menu items are displayed when the associated down-arrowhead button  is clicked-on. In some cases, these arrow heads are permanently visible (example 1), in other cases the list appears only when the relevant column is clicked-on (example 2).



Example 1 Example 2

2.4.2 Text/Numeric Entry

(Also known as ‘String entry’.)

Text entry and numeric entry techniques are identical except that for number only fields (e.g. tick rate entry) there is checking for valid numeric data.

On the Port Properties tab, non-numeric characters are disabled.

On the Register tab and Tables tab, numeric data is checked after an edit (i.e. when ENTER is pressed or when another cell is selected). If the data is invalid or out of range an error message appears and the data is restored to the original value.

Click somewhere within the text or numeric field. The cursor appears either at the right hand end of the existing entry, or within the existing entry, depending on the ‘click’ position.

The existing text can then be edited, deleted, overwritten, replaced etc. using normal keyboard entries.



Typical numeric entry field Typical text entry field

2.4.3 Multiple editing

This allows the user to select a number of registers and to edit them all in a single action:

Select the required registers (1 to 6 in the example below, though they need not be contiguous), with the control (<Ctrl>) key held down, make the required edit to one of the selected items (Register 2 in the example).

All the selected items have the edit applied to them.

0		...	16 Bit	0	↑
1	pid3.PV	...	16 Bit	0	↑
2	pid2.PV	...	16 Bit	0	↑
3	pid3.PV	...	16 Bit	0	↑
4	pid1.FallBack	...	32 Bit	0	↑
5	pid2.FallBack	...	32 Bit Swapped	0	↑
6	pid3.FallBack	...	BCD	0	↑

2.4.4 Multiple Item selection

Use <Shift> and the left mouse button to select a continuous range of registers.

Use <Ctrl> and the left mouse button to select multiple non-contiguous registers.

3 PORT PROPERTIES TAB

For some instrument versions, the Link settings area appears as shown below, where the serial communications parameters can be edited directly to match those of the rest of the system.

For further details, see:

Files

Operating Mode

TCP Properties

Link Settings

Instrument Options

Tick Rates

GWF Tables

GWF Size

Auto-Create tables

CNOMO Registers

Note

If the instrument Options configuration is defined in hidden library files, some fields can only be configured via the Instrument Properties dialog.


3.1 FILES

3.1.1 File Name

This gives the path name for the currently loaded .ujg file.

3.1.2 Database

This displays the database file currently being used. This may be changed by clicking on the button to the right of the field, and browsing for the required database.



3.2 OPERATING MODE

Operating mode selection is to be found in the Port Properties tab display, and allows the user to select Master or Slave and Serial or TCP modes of operation. Selections are greyed out or omitted for instruments which do not support the relevant mode.


Note

If the instrument type handles properties via the Instrument Options Editor, this section does not include the Slave Address property.

3.2.1 Mode

Allows the user to select 'Master' or 'Slave' for the instrument. For instruments which do not support master mode, the mode is automatically set to 'Slave' and is non-editable.

When master mode is selected, the 'Slave Addr.' Field (if present) is greyed-out (i.e. it is non-editable).



3.2.2 Slave Addr:

For older instruments (which do not support the system.opt file), this allows the user to select a Modbus Slave address (0 to 255) for the instrument. This address must be unique to the link. The field does not appear for instruments which do support the system.opt file - for such instruments the set up is carried out using the Instrument Option Editor accessed by clicking on the 'Instrument Options...' key.

3.2.3 Serial/TCP


These radio buttons allow Serial or TCP to be selected as the communications interface type. For instruments which do not support both, the relevant button is disabled (greyed out).

For instruments whose communications properties are configured via the Instrument Option Editor, the Link Settings panel presents a button to open the editor to allow communications parameters to be edited. For instruments that do not use the Instrument Options Editor, the communications parameters are set in the Link Settings panel.

SERIAL MODE


When Serial is selected the Baud Rate, Parity, Stop bits and Timeout need to be configured.

The Serial Port name is shown. If multiple Serial Ports are supported then the required Serial Port can be selected.



TCP MODE

If TCP is selected, then the TCP Port setting can be edited. The TCP Port number can be edited to any value between 0 and 65535 inclusive. The default Port number is 502.



When configuring a LIN instrument as a TCP master, the TCP port characteristics are set up in the TCP Properties dialog. The TCP Properties dialog can be accessed from the button to the right of the TCP radio button, the View menu, by using the short cut <Ctrl> + <D> or the TCP Properties tool.

3.2.4 TCP Properties (Devices tab)


Note

If a TCP (.uxm) file is read only, then so are the TCP properties which appear in this display.



Clicking on this tool opens the TCP properties display, a typical example of which is shown below. TCP properties are defined in a file called "<dbName>.uxm" in the instrument folder. The TCP Properties page can also be invoked from the TCP button on the Port Properties tab to the right of the TCP radio button, the View Menu 'TCP Properties' item, or by using the shortcut <Ctrl> + <D>.

There are two Tabs: 'Devices' and 'Properties'. The Devices tab is described within this topic; the 'Properties' tab in a separate topic.



The 'Devices' tab allows devices to be added and/or removed from the configuration.

The list of device properties will be displayed in a grid. Device properties include Name, Instrument number, Slave address, IP Address & Port.

NAME

ModbusTCP instrument device name can be any combination of alpha and numeric characters. See 'Editing Techniques' for text editing details.

INSTR. NO.

This number (between 1 and 255) is mandatory for GW-modbus and is the decimal Modbus address as defined in the GW tables "Instr No". See 'Editing Techniques' for numeric editing details.

SLAVE ADDR.

This number (between 1 and 255) is mandatory and is the decimal Modbus address of the ModbusTCP instrument device. See 'Editing Techniques' for numeric editing details.

3.2.4 TCP PROPERTIES (DEVICES TAB) (Cont.)

IP ADDRESS

This is mandatory and is the TCP/IP IP Address of the ModbusTCP instrument device or its TCP/IP address in standard 'decimal' notation*. If an IP Address is used, the Modbus comms needs to resolve it. See 'Editing Techniques' for text/numeric editing details.

*a.b.c.d, where a, b, c and d can have any value between 0 and 255


If an invalid address is entered, a warning message appears.

PORT

This is the decimal TCP/IP port number (0 to 65535) for the Modbus comms in the ModbusTCP instrument device. If this parameter is missing 502 is used by default. See 'Editing Techniques' for numeric editing details. Buttons are provided to Add a new device and to Remove a selected device.

3.2.5 TCP Properties (Properties Tab)

This TCP Properties tab is depicted below.



This display page allows the editing of the main TCP properties as defined in the .uxm file.

The "Defaults" button enables all properties to be reset to default values.

HOST RESOLUTION RETRY DELAY

The address of a Modbus TCP device can be specified by name or IP address.

If an IP address is used, no resolution effort is required, so the value for the host resolution retry delay is not relevant.

If a name is used, the system must 'resolve' the name to an IP address. Once the resolution process is successful, the resulting IP address is used for communications.

The Host resolution retry delay (default = 300000 msec (5 mins)) defines the frequency at which the system attempts to resolve the IP Address. Usually, the name is resolved immediately, but the process may fail and, in such a case, setting the delay to too low a value can reduce performance because of the processing effort involved.

3.2.5 TCP PROPERTIES (PROPERTIES TAB) (Cont.)

CONNECT INITIAL DELAY

The initial delay (default 100msec). incurred before attempting to connect to a Modbus TCP instrument device immediately its IP Address has been resolved. It is not recommended that this value is changed from the default.

Note that all connection requests are executed asynchronously to avoid blocking the Modbus communications in the 'connect()' call.

CONNECT RETRY 1 DELAY

The delay (default = 1000msec.) incurred before the first retry to connect to a Modbus TCP instrument device.

CONNECT RETRY 2 DELAY

The delay (default = 2000 msec.) incurred before the second retry to connect to a Modbus TCP instrument device.

CONNECT RETRY 3 DELAY

The delay (default = 5000 msec.) incurred before the third retry to connect to a Modbus TCP instrument device.

RECONNECT RETRY DELAY

The delay (default = 0 msec.) incurred between subsequent retries (after the third) to connect to a Modbus TCP instrument device.

RECONNECT NUM RETRIES

The number of retries (default = 5) to connect to a Modbus TCP instrument device at intervals of the Reconnect retry delay. Once all retries have been exhausted the algorithm reverts to Connect retry 1 delay and repeats.

ASYNC CONNECT POLL TIMEOUT

The period of time (default = 10 msec.) that the Modbus comms will wait for a connection to succeed or fail whilst polling for the completion of a connection request. This defines the amount of time the Modbus comms will hang in the 'select()' call.


ASYNC CONNECT TIMEOUT

The period of time (default = 0 msec.) that the Modbus comms will tolerate before cancelling a connection request that has yet to complete.

If this tuning parameter is missing a default value of 0 is applied. A value of 0 relies on the Windows implementation of the 'connect()' call to fail a connection request, any other value can be used to circumvent the time imposed by Windows.

3.3 LINK SETTINGS

'Link settings' is to be found on the Port Properties tab and appears as one of the figures below, depending on instrument variant.



3.3.1 Serial Settings

When Serial is selected as the Operating Mode, Baud Rate, Parity and Stop bits configuration fields are enabled, otherwise, they are greyed out.

3.3.2 Time out

The communications time out (0 to 65535 ms) can be entered here. Default is 500 ms.

3.3.3 Instrument Options...

In certain LIN instruments, some aspects, e.g. HMI, ports, etc. are handled using the Instrument Options Editor (LIN Modbus Capabilities Instrument Options) invoked by clicking on the 'Instrument Options...' button in the Link Settings area of the Port Properties tab. The instruments Editor has its own individual Help system which opens when the 'Help' button at the bottom of the Editor Window is operated.

The Instrument Options Editor can,

1. read/write changes into an instrument file
2. organise and present possible configuration options to the user
3. communicate with online instruments in order to both read their current options settings and download modified options files
4. instruct an instrument (via LIN messages) to reload any Instrument Option settings that do not require the power to first be isolated then re-applied
5. present the user with only the configuration options applicable to the target instrument

Note

The Instrument Options Editor can also be launched from both LINtools and Windows Explorer.




For successful communications, the Master/Slave etc. settings in the Operating Mode area must match the settings made in the Instrument Options Editor. See 'Port selection' for details of which port(s) should be configured for various instrument types.

3.3.3 INSTRUMENT OPTIONS (Cont.)

SERIAL MODE

When Serial mode is selected in the Modbus Tools, the ‘Instrument Options ...’ button opens the Instrument Options Editor with the ‘Serial’ properties selected.




- Port Select the required port. The settings for each port are specified in a column headed by the name of the port, e.g. ‘COM1’, ‘COM2’, etc. The selected port indicates the port used for Modbus Serial communications.
- Protocol The protocol for the given port needs to correspond to the operating mode specified in the Modbus Tools. For Master mode, select protocol Modbus-M. For Slave mode, select protocol Modbus-S.
- Address The LIN Slave Address.
- Baud, Parity and Stop bits
 Allows these serial properties to be specified.
- Timeout Allows the comms timeout to be specified.
- 3or 5 wire For use on targets where the Serial interface can be configured for 3-wire or 5-wire operation under program control.

3.3.3 instrument options (Cont.)

TCP MODE

When TCP mode is selected in the Modbus Tools, the **'Instrument Options ...'** button opens the Instrument Options Editor with the **EUNET'** (Ethernet) properties selected. 'Port Selection ' gives details of which port is suitable for which protocol for a number of instruments.



Timeout Allows the comms timeout to be specified.

Note

The Instrument Options Editor uses the instrument type specified in the instrument folder in order to apply rules about which options are supported. These capabilities are based on the LIN Database (.dbf) file that is specified as part of the Modbus Configuration. If there is a conflict between these instrument types, i.e. if the Modbus Tools has selected a LIN Database (.dbf) file for a different instrument type to that specified in the instrument folder then a conflict may arise in getting the Instrument Options settings to correspond to those in the Modbus Tools. If this occurs, then either change the instrument type in the instrument folder or move the Modbus configuration (.ujg) and corresponding LIN database file (.dbf) to a different folder.


3.3.3 INSTRUMENT OPTIONS (Cont.)

PORT SELECTION

This topic describes how to determine the relevant port for configuration.

When TCP and Master are selected in the Operating mode area of the Port properties tab, then ENET 4 should be used. Use ENET3 for TCP slaves.


If Serial Master or Slave is selected, then click on the 'Instrument Options' button in the Link Settings area of the Port properties page. In the resulting display, use the pull down menus to display and select a suitable Master/Slave option for each port.



Note:

As shown above, the pull down menu appears when the relevant area is clicked on.

3.4 TICK RATES



If the LIN instrument does not support tick rates, and/or if the instrument is set up as a Modbus slave, the Tick Rate edit fields are disabled.


If the LIN instrument supports Tick Rates, and it is configured as a Modbus Master, then this area of the Port Properties tab allows values (between 0 and 65535 ms) to be entered for the Slow, Medium and Fast tick rates.

Each table of registers is assigned one of these tick rates to define the frequency at which it is scanned. The tick rate associated with each table can be modified in the Tables tab.

The tick rate associated with an individual register can be selected (slow, medium or fast) in the relevant Register tab or Digital tab. In Auto Create tables mode, this affects the allocation of registers to tables.

3.5 GWF TABLES

GWF Tables is to be found in the 'Port Properties tab'.




Number The number of tables currently in use.

Max Displays the maximum number of gateway tables available for the current instrument (see LIN Instrument Modbus Capabilities).

3.6 GWF SIZE

GWF Size is to be found in the 'Port Properties' tab.




Max Size The memory space available within the LIN instrument, into which Modbus data (as defined in the GWF file) can be downloaded.

Size The amount of memory being used by the current Modbus configuration.

Free The remaining amount of memory, available for use.

3.7 AUTO CREATE TABLES

'Auto-create Tables' is to be found in the Port Properties tab.



With this option ticked (default), the allocation of registers to tables is automatic. User editing of the tables is restricted if 'Auto-Create' is selected.

Contiguous blocks of registers associated with a given Modbus slave are assigned to a single table (if possible). All registers contained in one table are scanned in a single Modbus transaction.

If a contiguous block of registers exceeds the maximum number for a single transaction (2000 digitals, 125 registers) then the excess registers are assigned to a new table.

If, in an otherwise contiguous block of registers, there is a gap that does not exceed the maximum allowable gap (320 digitals, 20 registers), then the registers will still be assigned to a single table.

If the tick rate of an individual register is modified, then that register will be assigned to a new table.

If Auto create tables is not ticked, the user must specify type, slave address/instrument number, offset and count for each table, manually. Tables must be defined (in the Tables tab) for all registers to be scanned.

3.7.1 Diagnostic Table

In auto-create tables mode, a further option 'Diagnostic table' is enabled for user selection. If selected, a diagnostic table will be created consisting of a special set of registers containing status and control bits to allow the LIN database to interact with the MODBUS drivers. The default diagnostic registers will be added into the Diagnostic tab register view.

When not in auto-create tables, a single Diagnostic tab can be manually configured in the Tables tab.

3.7.2 CNOMO Response

Certain instrument types have the ability to respond to specific CNOMO registers (LIN Modbus Capabilities CNOMO Response).

The CNOMO registers apply to specific data that can be read at pre-defined offsets namely Manufacturer's identity (121), Device type (122), Device Version (123) and a further register Device Heartbeat (124) reserved for future use.

If an instrument is capable of a CNOMO response, then this can be enabled via the check-box on the Auto-create panel of the Port Properties tab.

If CNOMO response is enabled then the user will be prevented from using registers in the CNOMO range, 121-124. If a user adds registers that span these locations then those registers will be reserved as read-only for CNOMO use and can not be re-assigned by the user.

120	16 Bit	0	M←S	4	
121	16 Bit	0	M←S	4	Reserved CNOMO register: Manufacturer's ID
122	16 Bit	0	M←S	4	Reserved CNOMO register: Device type
123	16 Bit	0	M←S	4	Reserved CNOMO register: Device Version
124	16 Bit	0	M←S	4	Reserved CNOMO register: (for future use)
125	16 Bit	0	M←S	4	

If an attempt is made to add 32-bit registers that overlap with the CNOMO offsets then 16-bit registers will be inserted alongside the CCNOMO registers to maintain even boundary alignment of 32-bit registers.

WHAT IS A CNOMO REGISTER?

The Comité de Normalisation des Moyens de production (CNOMO) registers are set of pre-defined offset values that return manufacturer and product details value. These Offset values can only be used when the instrument is configured to operate in Modbus Slave mode.

It return manufacturer's identity, Device type i.e. LIN ident value, and Device version values on the Register tab at pre-defined Offset values 121, 122, and 123 respectively.

Note

The Offset value 124, displays the instrument status, Device heartbeat.

4 REGISTER TAB

Port Properties Register Digital Diagnostic Tables							
Instr No.	Offset	Field	Format	Decimal Places	Read-Write (M-----S)	Table	Tick R (ms)
10	100		16 Bit	0	M><S	1	Med.
10	101		16 Bit	0	M←S	1	Med.
10	102-3	pid1.PV	32 Bit		M←S	1	Med.
10	104-5		32 Bit Swapped		M←S	1	Med.
10	106		16 Bit	0	M←S	1	Med.
10	107		16 Bit	0	M←S	1	Med.
10	108		16 Bit	0	M←S	1	Med.
10	109		16 Bit	0	M←S	1	Med.
10	500		16 Bit	0	M←S	5	Med.
10	501		16 Bit	0	M←S	5	Med.
10	502		16 Bit	0	M←S	5	Med.
10	503	pid1.RemoteSP	16 Bit	0	M←S	5	Med.
10	504		16 Bit	0	M←S	5	Med.
10	505		16 Bit	0	M←S	5	Med.
11	100		16 Bit	0	M←S	6	Med.
11	101		16 Bit	0	M←S	6	Med.
11	102		16 Bit	0	M←S	6	Med.
11	103		16 Bit	0	M←S	6	Med.

For Help, press F1 Mode: MASTER AUTO create tables 5% NUM

This page shows the analogue registers configured for the various Modbus instruments.

To select a register for edit, click anywhere within the relevant row.

Use <Shift> and the left mouse button to select a continuous range of registers.

Use <Ctrl> and the left mouse button to select multiple non-contiguous registers.

See also:

Adding Registers

Moving Register

Cut, Copy and Paste

Unmapped Registers

Slave Addr

Instrument No.

Offset

Field

Format

Decimal places

32-Bit Date and Time

Read-Write

Table

Tick Rate

Description

4.1 ADDING REGISTERS

To add further registers:

Click on the 'Add Registers' Tool ,

Use the edit menu 'Add Registers' entry,

Use the right click 'Add Registers' entry,

Use the shortcut <Ctrl> + <R>.


Double-click on a blank row in the Register grid.

Double-click on the Slave Addr./Instr. No. or Offset field of an existing register to invoke the Add Registers dialogue, with initial values based on the selected register.

Note

The Add Registers dialog enables the user to add new registers. It cannot be used to modify fields of an existing register.

Any of the above calls the 'Add Registers' dialogue box, allowing the user to define further registers. The default characteristics are the same as those of the highlighted register, except that the Offset value is set to the next available offset. Typical displays for analogue and digital registers are shown below.



In Auto-create tables mode, all new registers are assigned to a table. When not in 'Auto-create tables' mode, new registers are 'unassigned'.

Note:

Data in Modbus Tables will become corrupt if registers containing 32-bit or 32-bit Swapped data type runs contiguously between different Tables.

4.1.1 Slave Addr.

Shows the slave address of the highlighted register. This may be edited to any existing or new slave address within the range 0 to 255 inclusive. In slave mode the value is automatically set to the LIN instrument slave number defined in the Operating Mode area of the Port Properties tab.

Replaced by 'Inst. No.' (below) for Operating mode = TCP Master.

4.1.2 Inst. No.

For Master TCP mode only, this is the decimal Logical LIN instrument number (1 to 255) which corresponds with the defined physical TCP address of a Modbus slave instrument.

For other modes, Inst. No. is replaced by 'Slave Addr.', above.

See also TCP Properties

4.1.3 Offset

Shows the first available offset, in the table associated with the highlighted register. The offset value may be between 0 and 65535 inclusive.

If an attempt is made to add a range of registers that conflicts with one or more existing registers, then only intervening registers are added. Pre-existing registers are NOT overwritten (i.e. any existing mappings or register field edits are retained).

4.1.4 Count

The number (0 to 65535) of new registers to be added, starting at the Offset address.

4.1.5 Format


Allows a number format to be selected for the field.




4.1.6 DP

Allows the user to select the number of decimal places to be applied, between none and four.


4.1.7 Read-Write



This picklist defines the direction in which the data will pass between the Master and the Slave.




No data is passed between the Master and the Slave.




Master: This register is periodically updated with data requested by the master from the Slave.

Slave: The content of this register can be read by the Master.



Master: When the content of this register changes, it is written by the Master to the Slave.

Slave: The content of this register is intermittently updated by the Master.



Master: When the content of this register is changed by the Master, it is written to the Slave.

Slave: When the content of this register is changed by the Slave, it is written to the Master.

The LIN instrument Operating Mode selection is made in the Port Properties tab.

4.2 MOVING REGISTERS

Once a register has been added into the Register grid, the properties of the register may be edited. However, the Slave Addr./Instr. No. and Offset fields that uniquely identify the register may not be edited.


If it is required to move or copy existing registers to a different Slave Addr./Instr. No. and Offset, this can be achieved using the Cut/Copy and Paste/Paste Special operations in the Edit menu.

To move selected registers, use the Cut (Ctrl-X) in the Edit menu. The registers will be removed from the grid. To relocate the registers, use the Paste Special (Ctrl-Q) operation in the Edit menu. This will present a dialog allowing the specification of a user-defined location. The removed registers will then be re-inserted into the grid at the new Slave Addr./Instr. No. and Offset locations.


4.2.1 Cut, Copy and Paste

Analogue and digital registers can be deleted, copied or moved using the Delete, Cut, Copy, Paste and Paste Special operations, accessed via the Edit menu, the context (right-click) menu or the tool bar tools (not delete).

If any attempt is made to paste overlapping registers, a warning message appears, giving the user the opportunity to overwrite those registers which are overlapped, to paste to a different location or to cancel the paste operation.



Clicking on Paste To... calls the following display, allowing the user to edit the paste destination.



4.3 UNMAPPED REGISTERS

When not in Auto-create mode, tables can be configured manually.

Corresponding unmapped (virtual) registers will be automatically added into the appropriate registers view. This saves the user the extra effort of creating registers that have already been defined within the range of an existing table.

Unmapped registers are displayed in italics.

Groups of unmapped registers may be displayed in a compressed format (single row)

210	header.Status.ColdStrt	...	1	M >< s	2	Med.
211	header.Alarms.BattLow	...	1	M ↔ s	2	Med.
212	header.Alarms.Software	...	1	M ← s	2	Med.
+ 213(2)					2	<i>Unmapped Registers 213-214 (2)</i>
215	pid1.Alarms.Software	...	1	M ← s	2	Med.

or expanded using the +/- button to show the individual registers.

210	header.Status.ColdStrt	...	1	M >< s	2	Med.
211	header.Alarms.BattLow	...	1	M ↔ s	2	Med.
212	header.Alarms.Software	...	1	M ← s	2	Med.
- 213(2)					2	<i>Unmapped Registers 213-214 (2)</i>
213		...	1		2	<i>Unmapped</i>
214		...	1		2	<i>Unmapped</i>
215	pid1.Alarms.Software	...	1	M ← s	2	Med.

In order to configure an unmapped register, click on a grid cell to edit the data in the normal way. When data is applied to an unmapped register, it is no longer a virtual register and is no longer displayed in italics.

4.4 COLUMN HEADINGS

4.4.1 Slave Addr

The address (in the range 0 to 255) of the slave instrument. (See 'Editing techniques' for text/numeric editing details)

In Auto-Create mode the Slave Addr. is not editable.

In Slave mode, the Slave Addr. of the LIN instrument being configured is used.

In TCP Master mode, 'Slave Addr.' is replaced by 'Instrument No.'.

See also TCP properties.

4.4.2 Instr No.

For Master TCP mode only, this is the decimal Logical LIN instrument number (0 to 255) which corresponds with the defined physical TCP address of a Modbus slave instrument.

For other modes, Instrument No is replaced by Slave Addr..

See also TCP Properties

4.4.3 Offset

This defines the offset for each register in the range 0 to 65535 inclusive.

If the number format of a register is 32 bit, then the register occupies two adjacent offset addresses.

Digitals defined as having width = n, occupy n adjacent offset addresses. For n > 1, the register may be displayed in a compressed format (single row) or expanded using the +/- button to show the individual bit mappings. See 'Digital Tab' for examples.


Multiple bit digitals must start at an 8 bit boundary relative to the start of the table or an error will be reported.

4.4.4 Field



The LIN Field value may be edited directly, by typing-in the relevant block and field name.

Alternatively, the LIN database browser can be opened (by clicking on the browse button to the right of the field value, (see above)) to provide the user with a quick and easy method of assigning LIN blocks to registers. The browser can be 'pinned' by clicking on the 'pin' icon.



Only LIN references which have data types valid for the type of register being mapped are offered for selection, as listed below.

Field names can be set to 'empty' (i.e. unmapped) by clicking on the Clear button. Unmapped registers do not result in errors.

ANALOGUE REGISTER DATA TYPES

Analogue registers can be mapped to LIN fields of the following types:

- Single
- Long
- UnsignedLong
- String
- Date
- Time

4.4.4 FIELD (Cont.)

DIGITAL REGISTER DATA TYPES

Digital registers can be mapped to LIN fields of the following types:

Boolean

Alarm Bitfield

Subfield 8 or subfield8.bitfield

Subfield 16 or subfield16.bitfield

4.4.5 Format

Allows the number format to be selected from a list.

Only those formats supported by the LIN instrument being configured are included in the list. See also LIN Instrument Modbus Capabilities.



16-bit The normal register format

32-bit IEEE format (if supported)

32-bit swapped IEEE format but with low order word first (if supported)

BCD 16-bit binary coded decimal.


Note

If either of the 32-bit formats is selected, the offset value changes to include two adjacent registers, and the decimal places selection is disabled. 32-bit formats must not run contiguously between different Tables.

Offset	Field	Format	Decimal Places
100		16 Bit	0
101		16 Bit	0
102-3	pid1.PV	32 Bit	
104-5	pid2.PV	32 Bit	
106-7	pid3.PV	32 Bit	
108	pid4 Mode	16 Bit	1

TIME AND DATE 32-BIT FORMAT

If either 32-bit or 32-bit Swapped format is selected, an analog register can be mapped to a Time or Date function block field. In this case, the 32-bit Time or Date format is supported in the adjacent column (Decimal Places).




A 32-bit Date field is read only format, ISO8601.

A 32-bit Time field may be selected between ISO8601 and POSIX.

For further details see 32-bit Date and Time.

4.4.6 Decimal Places

Allows the selection of the number of decimal places between none (e.g. 1234.) and four (.1234).




This field is enabled only when registers having 16 bit or BCD format are being edited.


Note that in the case of a 32-bit format register that is mapped to a Time or Date function block field, the Time or Date format is supported in the decimal places column.

Format	Decimal Places	Read-Write (M -----)
16 Bit	0	M ← S
32 Bit Swapped	ISO8601	M ← S
	POSIX	
	ISO8601	


4.4.7 Read-Write



This picklist defines the direction in which the data will pass between the Master and the Slave.




No data is passed between the Master and the Slave.




Master: This register is periodically updated with data requested by the master from the Slave.

Slave: The content of this register can be read by the Master.



Master: When the content of this register changes, it is written by the Master to the Slave.

Slave: The content of this register is intermittently updated by the Master.



Master: When the content of this register is changed by the Master, it is written to the Slave.

Slave: When the content of this register is changed by the Slave, it is written to the Master.

The LIN instrument Operating Mode selection is made in the Port Properties tab.

4.4.8 Table


This read only value shows the table number to which Modbus registers have been assigned. Contiguous tables for a given slave are separated by a thick grey line.

Each table can have only one tick rate associated with it. In auto-create tables mode, changing the tick rate of one or more registers in a table results in the creation of a new table just for those registers.

Note

Tick rate can be edited only when 'Master' is selected in 'Operating Mode' in the 'Port Properties tab'.

4.4.9 Tick Rate



Applies only to instruments that support 'Tick rates'.

See also LIN Instrument Modbus Capabilities.

In master mode, this allows slow, medium or fast to be selected for each register. (See 'Editing techniques' for drop-down menus description)

Each table can have only one tick rate associated with it. In auto-create tables mode changing the tick rate of one or more registers in a table will result in the creation of a new table just for those registers.

Actual values for the three tick rates are entered in the 'Tick Rates' area of the Port Properties tab.


4.4.10 Description

This is a free-format text entry description for the table, of up to 100 characters.


See 'Editing Techniques' for text editing details.

4.4.11 Pinned

When pinned the browser window remains open, allowing the user continuously to assign registers to fields without having to close and re-open the window each time.



Pin icon when window unpinned.



Pin icon when window pinned.

5 DIGITAL TAB

Port Properties Register Digital Diagnostic Tables							
Instr No.	Offset	Field	Width	Read-Write (M ----- S)	Table	Tick Rate (ms)	De
10	203	header .Alarms.BattLow	1	M←S	2	Med.	
10	204		1	M←S	2	Med.	
10	205		1	M←S	2	Med.	
10	206		1	M←S	2	Med.	
10	207		1	M←S	2	Med.	
11	390		1	M←S	4	Med.	
11	391		1	M←S	4	Med.	
11	+ 392(8)				4		U
11	400-415	header .Options	16	M←S	4	Med.	
11	416	bid2 .Alarms.HighAbs	1	M←S	4	Med.	
11		Expand/Compress Multi-bit fields	1	M←S	4	Med.	

For Help, press F1 Mode: MASTER AUTO create tables 6% NUI

This page shows the digital registers configured for the various Modbus instruments. To select a register for edit, it can be clicked on anywhere in the relevant row.

Use <Shift> and the left mouse button to select a continuous range of registers.

Use <Ctrl> and the left mouse button to select multiple non-contiguous registers.

See also:

Adding Registers

Cut, Copy, Paste

Unmapped Registers

Slave Addr.

Instrument No.

Offset

Field

Width

Read-Write

Table

Tick Rate

Description

5.1 COLUMN HEADINGS

5.1.1 Width

o.	Offset	Field	Width
	200	pid1 .Alarms .Software	1
	201	pid2 .Alarms .Software	1
	202	pid1 Longusertags .ModeSel.	1
	203	header .Alarms .BattLow	1
+	204(4)		
+	208-15	pid1 .Options	8
	216-23	pid2 .SelMode	8
	216	pid2 .SelMode .SelHold	1
		Expand/Compress Multi-bit fields	1
		BITTrack	1

Digital registers have a width property. This defines the number of bits that are mapped to a specified LIN field.

If a digital register is mapped to multiple bits then the register may be displayed in a compressed format (single row) (208-215 above) or expanded using the +/- button to show the individual bit mappings (216-223 above).

Note

Multiple bit registers must start at an 8 bit boundary, relative to the start of the table, or an error will be reported.

6 DIAGNOSTIC TAB

Offset	Field	Format	Decimal Places	Read-Write (M ----- S)	Table	Tick Rate (ms)	Description
0		16 Bit	0	M ↔ S	3	N/A	Ur
1		16 Bit	0	M ↔ S	3	N/A	Fla
2		16 Bit	0	M ↔ S	3	N/A	Dir
3		16 Bit	0	M ↔ S	3	N/A	Qu
4		16 Bit	0	M ↔ S	3	N/A	Inp
5		16 Bit	0	M ↔ S	3	N/A	Ur
6		16 Bit	0	M ↔ S	3	N/A	Ur
7		16 Bit	0	M ↔ S	3	N/A	Cc
8		16 Bit	0	M ↔ S	3	N/A	Ur
9		16 Bit	0	M ↔ S	3	N/A	Ur
10		16 Bit	0	M ↔ S	3	N/A	Ur
11		16 Bit	0	M ↔ S	3	N/A	Me
12		16 Bit	0	M ↔ S	3	N/A	Sc

For Help, press F1 Mode: MASTER AUTO create tables 6% NUM

The diagnostic table is a special set of registers containing status and control bits to allow the LIN database to interact with the MODBUS drivers. A diagnostic table allows MODBUS operation to be controlled, or diagnostic information to be presented to the LIN database. Only one diagnostic table need be configured per MODBUS configuration.

In auto-create tables mode, a diagnostic table is created and the default diagnostic registers are added into the Diagnostic register view.

When not in auto-create tables, a single Diagnostic table can be manually configured on the Tables tab.

The diagnostic table is a special set of registers containing status and control bits to allow the LIN database to interact with the MODBUS tables. A diagnostic table allows MODBUS operation to be controlled, or diagnostic information to be presented to the LIN database. Only one diagnostic table need be configured per MODBUS configuration.

See also:

Offset

Field

Format

Decimal Places

Read-Write

Table

Tick Rate

Description

The registers of a diagnostic table are in two distinct sets --- the first sixteen at default addresses 0 - 15, and the following registers at addresses 16 onwards (one per table) up to the maximum number of tables supported.

6.1 REGISTERS 1 TO 16

The first set of registers (with default addresses 0 to 15) are for internal diagnostic use, and are read-only to the user. They present general information on the operation of the MODBUS and their functions are independent of whether the instrument is operating as a master or a slave. The following lists these registers and their functions:


- 0 (Unused)
- 1 Flags 32-bit configuration errors (1 bit per table)
- 2 Diagnostic register, bits currently allocated: Bit 5 --- Slave in listen-only mode
- 3 Query data as transmitted by function code 8 sub code 0
- 4 Input delimiter as transmitted by function code 8 sub code 3
- 5 (Unused)
- 6 (Unused)
- 7 Count of error messages sent by slave
- 8 (Unused)
- 9 (Unused)
- 10 (Unused)
- 11 Master polling task: cycle period in 4 ms ticks
- 12 Scanner task: time to check all tables in 4 ms ticks
- 13 Scanner task: time used last time scheduled in 4 ms ticks
- 14 Scanner task: time used for last delay in 4 ms ticks
- 15 (Unused)

6.2 REGISTERS 17 ONWARDS

The second set of registers (with default addresses 16 onwards) allows individual tables in the configuration to be monitored and controlled. Each register in the diagnostic table is automatically allocated to an entire table in the configuration. Specifically, the diagnostic register at default address 16 is assigned to table 1, the register at address 17 is assigned to table 2, and so on up to the max number of tables.

The function of this second set of registers depends on the systems current operating mode, Master Mode, or Slave Mode.

6.2.1 Master Mode



WRITE ERROR CODE

Normally zero. Otherwise it contains the error code associated with the last write to this table.

READ ERROR CODE

Normally zero. Otherwise it contains an error code associated with the reading of this table.

DISABLE WRITE

Setting this bit to 1 stops the master writing to the slave across the serial link.

Note that when this bit is reset to 0, a write is forced to all the values in the table.

SCAN COMPLETED

This sets to 1 when the master has completed a scan of the slave. When operating in single scan mode, it indicates that the scan is finished and the data is available for use. It resets when the *single scan* bit is set, as described in the example below.

SINGLE SCAN

This is used in conjunction with the disable continuous scan bit. It allows a database sequence to initialise a single scan.

DISABLE CONTINUOUS SCAN

Setting this bit to 1 stops the master polling the slave across the serial link.

ONLINE

This sets to 1 when the slave is responding to the scanning routines.


The single scan and scan completed bits are used together when a slave can be polled only under specific circumstances. A small sequence must be implemented to ensure that these bits are used correctly. The 'disable continuous scan' bit must also be set.

The suggested sequence for these operations is:

- Reset the single scan bit
- Wait till scan completed reset
- Set the single scan bit
- Wait till scan completed set
- The data is now valid
- Loop back to step 1

6.2.2 Slave mode

In slave mode the diagnostic register includes bits that allow monitoring and control of the associated MODBUS table by the strategy running in the LIN database.



The values in the register are used in the following way:

DISABLE WRITE

Setting this bit disables writes across the MODBUS serial link to the associated table. The slave will return error code 8 (see Table, Exception responses).

ONLINE

This bit is set to 1 if the table has been written to or read from in the period defined in Time out.

In master mode the diagnostic register includes bits which allow control by a database sequence of read/write operations when required by the application:

6.3 DIAGNOSTIC FUNCTION CODES

Accessed by Modbus function code 8

Sub-Code	Data sent	Description
0000	xxxx	Echoes the data sent.
0001	0000	Restarts.
	FF00	Resets the diagnostic counters, and re-enables response if the slave has been placed in listen-only mode by sub-code 4.
0002	xxxx	Returns the diagnostic register (always zero).
0003	ABxx	Changes the ASCII delimiter (Echoes the data sent).
0004	0000	Forces Listen-only mode. There is no response to this function.
000A	0000	Resets all counters.
000B		Not supported.
000C	0000	Returns the number of CRC errors detected in messages addressed to this slave.
000D	0000	Returns the number of error messages returned by this slave.
000E	0000	Returns the number of correct messages addressed to this slave.
000F	0000	Returns a count of the number of times the slave has not responded to a valid message (e.g. an unsupported function or a buffering problem in the slave.)
0010	0000	Always returns 0.
0011	0000	Always returns 0.
0012	0000	Returns the count of character errors received at the slave (i.e. overrun + parity + framing errors).
0013		Not supported.
0014		Not supported.

6.4 EXCEPTION RESPONSES

The following error codes can be stored in bits 8 to B or C to F described in 'Diagnostic Tab'

01 Illegal function The function is illegal or not supported

02 Illegal data address The address does not exist within this slave

03 Illegal data value The value in the data field is invalid

04 Failure in associated device

05 ACK (Acknowledge)

06 Busy, rejected message

07 NAK (Negative acknowledge)

08 Write error. The data has been write protected via a bit in the appropriate diagnostic register. See 'Diagnostic Tab'

09 Zone overlap

0A Header error

0B Slave absent

0C CRC error

0D Write inhibited. The server has requested that a value be written to a slave, but none of the write codes is enabled for the table

0E Incorrect length. The length of the response message does not match the expected length

0F Slave Time out. No response was detected within the period defined in the Time-out parameter

7 TABLES TAB

Port Properties Register Digital Diagnostic Tables								
Table	Type	Instr No.	Offset	Count	Scan Count	Function Codes	Tick Rate (ms)	Description
1	REGISTER	10	100	10	10	3 4 6 16	Med.	
2	DIGITAL	10	0	208	208	1 2 5 15	Med.	
3	DIAGNOSTIC	N/A	0	80	80	N/A	N/A	
4	DIGITAL	11	390	28	28	1 2 5 15	Med.	
5	REGISTER	10	500	6	6	3 4 6 16	Med.	
6	REGISTER	11	100	8	8	3 4 6 16	Med.	
7	UNUSED	0	0	0	0	- - - -	Med.	
8	UNUSED	0	0	0	1	- - - -	Med.	
9	UNUSED	0	0	0	1	- - - -	Med.	
10	UNUSED	0	0	0	1	- - - -	Med.	
11	UNUSED	0	0	0	1	- - - -	Med.	
12	UNUSED	0	0	0	1	- - - -	Med.	
13	UNUSED	0	0	0	1	- - - -	Med.	

For Help, press F1 Mode: MASTER AUTO create tables 6%

The Tables tab includes an entry for every configurable table for a given LIN target instrument. The maximum number of tables that can be configured for a given instrument is dependent on the LIN target library type. See also Lin Instrument Modbus capabilities.

Table data that is incomplete or invalid is displayed in red and a corresponding message given in the report window.

In Auto-Create mode, tables are automatically configured as registers are added. In this case Table Type, Slave, Offset and Count are read-only.

When not in Auto-Create mode, tables can be configured manually. Corresponding virtual registers will be added as new tables are configured. See also Unmapped Registers.

In Slave mode, the Scan Count, Function Codes and Tick-Rate are not shown.

7.1.1 Editing cells on the tables grid

Clicking on a cell activates an appropriate editor. For further details, see:

Table Number

Table Type

Slave Addr.

Instrument No.

Offset

Count

Scan Count

Function codes

Tick rates

Description

7.1.2 Table Number

The tables tab contains a list of all available tables, whether used or not. The table number is not editable.

7.1.3 Table Type

Displays the type of registers associated with each table. (See 'Editing techniques' for drop-down menus description)

In Auto-Create Mode the table type will be read-only. Otherwise, the table type may be selected as REGISTER, DIGITAL, DIAGNOSTIC or UNUSED.




7.1.4 Function Codes

The function codes that may be used to transfer registers assigned to this table.

In Slave mode, the Function Codes are not shown.

Clicking once within the cell, calls the Modbus Function Codes box as shown below. This allows the currently allocated codes to be enabled/disabled for the table. Function codes are automatically allocated according to register type.



The possible function codes are as follows:

- Read digital output status
- Read digital input status
- Read analogue output registers
- Read analogue input registers
- Write single digital output
- Write single analogue output register
- Write multiple digital outputs
- Write multiple analogue output registers

8 MENU BAR

File Edit View Help

The menu bar contains the following items, each of which is described in one or more separate topics:


File menu

Edit menu

View menu

Help menu


8.1 FILE MENU



8.1.1 New

This command is used to create a new Modbus configuration. The user is prompted to select a LIN Database file to be referenced for LIN block field tag browsing.

Shortcuts:


'New' tool ,

<Ctrl> + <N>.


8.1.2 Open

This tool is used to open an existing Modbus configuration. If another 'instance' of the selected file is already open, a message appears asking if a new instance of the file is to be opened or if the existing instance should be switched to. Where several instances are open, 'Switch To...' opens the first instance.

If a LIN database is not specified, the user is prompted to select a LIN Database file to be referenced for LIN block field tag browsing.



Shortcuts:


'Open' tool ,

<Ctrl> + <O>.

8.1.3 Save

This command is used to save the active Modbus configuration to its current name and directory (folder). The first time a configuration is saved, the 'Save As' dialogue box appears to allow the configuration path name to be defined.


Shortcuts:

'Save' tool ,

<Ctrl> + <S>.

8.1.4 Save As...

The 'Save As' dialogue box appears to allow the configuration to be saved to a new location.




8.1.5 Save Special

When clicked-on, this provides a single item menu selection 'Text Listing'. If selected, Text Listing creates a 'simple text' (.txt) file containing the Modbus configuration.

8.1.6 Import CSV

This command is used to load a CSV format Modbus configuration. When the required file has been selected from the file dialogue, the user is asked to define a delimiter from Comma, tab or space.


Shortcut: <Ctrl> + <I>.




8.1.7 Export CSV

This command saves the current configuration file in CSV format. When the required file name has been entered in the file dialogue, the user is asked to define a delimiter from Comma, tab or space.


Shortcut <Ctrl> + <E>.



8.1.8 Page Setup



This command allows the user to define the text entries in the title block that appears at the bottom of the page(s) when the configuration is printed. 'Text 1' to 'Text 5' in the figure above appear in the locations shown in the figure below. Date, page numbering, and the file and database names are non editable.

Text 5 			Text 1	Issue: Text 4
	File: tact.ujg	DB: tact.DBF	Text 2	Date: 25/05/05
			Text 3	Page: 1 of 5

BITMAP PATH AND FILENAME

This allows the user to select a bitmap image (e.g. a logo) to appear below the Text 5 in the bottom left hand corner of the printed page(s). The path name can be typed in, or can be browsed for using the 'Browse' key.

8.1.9 Print setup

This command allows printer default settings to be entered for printed documents.


8.1.10 Print Preview

This command displays the active Modbus configuration as it would appear when printed. The Print preview toolbar allows the user to view one or two pages at a time, move forwards and backwards through the document, zoom into and out of pages, and to initiate the print.


8.1.11 Print

This command calls the standard Printer Dialogue allowing the user to select a printer, paper source, single or double sided, number of copies etc. for the printed configuration. The default values can be set up in 'Print setup' described above.

Shortcuts:

Print tool ,

<Ctrl> + <P>.



Printed configurations consist of the following pages

Port properties information,

Table information

Diagnostics information


Modbus tables (one page for each configured table)

8.1.12 Previous configurations

This is a list of the last four Modbus configurations used. A configurations can be opened by clicking on the relevant file name.

8.1.13 Exit

This command quits the current Modbus Tools session. If there are unsaved changes, the user is asked if the changes are to be saved.



Shortcuts:

<Alt> + <F4>.

Double click on the application control menu, then on 'Close'.

8.2 EDIT MENU


Edit

Undo Add Registers	Ctrl+Z
Redo	Ctrl+Y
Cut	Ctrl+X
Copy	Ctrl+C
Paste	Ctrl+V
Paste Special...	Ctrl+Q
Delete	Del
Goto	Ctrl+G
Add Registers	Ctrl+R
Add Table	Ctrl+T
Autocreate	▶

8.2.1 Undo (last action)

Use this command to undo up to the last six editing actions (if possible). The item is 'greyed out' if there is no previous action to be 'undone'.

Shortcuts:

'Undo' tool ,


<Ctrl> + <Z>,

Right click menu 'Undo (last action)' item.

8.2.2 Redo (last action)

Use this command to reverse the last undo action (if possible). The item is 'greyed out' if there is no previous undo action to be 'redone'.

Shortcuts:

'Redo' tool ,


<Ctrl> + <Y>,

Right-click menu 'Redo (last action)' item.

8.2.3 Cut

Deletes the current selected registers from the configuration and places them on the clipboard, ready for pasting elsewhere. The item is 'greyed out' if no registers are selected.

Shortcuts:

'Cut' tool ,


<Ctrl> + <X>,

Right-click menu 'Cut' item.

8.2.4 Copy

Copies the current selected registers to the clipboard, ready for pasting elsewhere. The original registers remain unchanged. The item is 'greyed out' if no registers are selected.

Shortcuts:

'Copy' tool ,


<Ctrl> + <C>,

Right-click menu 'Copy' item.

8.2.5 Paste

This inserts a copy of the clipboard register data into the document. The clipboard contents remain unchanged. The item is 'greyed out' if the clipboard is empty.

Shortcuts:

'Paste' tool ,


<Ctrl> + <P>,

Right click menu 'Paste' item.

8.2.6 Paste Special...

This inserts a copy of the clipboard register data into a new, user definable location. The clipboard contents remain unchanged. The item is 'greyed out' if the clipboard is empty or if multiple slaves are included in the clipboard content.

Shortcuts:

'Paste To' tool ,

<Ctrl> + <Q>,

Right-click menu item 'Paste Special...'

8.2.7 Delete

This item deletes currently selected registers from the configuration. The item is 'greyed out' if no registers are selected. Unlike the 'Cut' command, deleted registers are not placed on the clipboard and cannot thus be 'pasted'.

Shortcuts:

<Delete> key,

Right-click menu item 'Delete'.

8.2.8 Goto

From the 'Tables' tab, this command moves the user to the Register or Digital tab which contains the highlighted table, and highlights the first register assigned to that table.

From the Register tab or Digital tab, the command moves the user to the 'Tables tab' and selects the table that the selected register is assigned to.

If multiple registers are selected, then the table associated with the first of the selected registers is moved to.

If the register is not assigned to a table, no navigation takes place.

The item is 'greyed out' if no registers are selected.

Shortcuts:

<Ctrl> + <G>,

Right-click menu 'Goto' item.

8.2.9 Add Registers

This is used to add registers to the table configuration, as described in 'Adding Registers'.

Shortcut:

'Add registers' tool 

8.2.10 Add Table

This command is not available in 'Auto create tables' mode.

All selected 'unassigned' registers are placed into a new table by this command.

Assigned registers are ignored.

Only those registers associated with the same slave as the first unassigned register will be included in the new table.


This command is greyed out if there are no selected, unassigned registers.

Shortcuts:

<Ctrl> + <T>


Right-click menu 'Add Table' item.

8.2.11 Autocreate



This allows the user to map programmer block fields to MODBUS registers automatically. This feature applies only to MODBUS slave devices which support PROGCHAN blocks; the selection being disabled for other devices and for Profibus communications.

When clicked on, a dialogue box opens, as shown below.



STARTING ADDRESS FOR NEW REGISTERS:

Allows the user to choose an address at which to start creating new registers. This is set by default to 10000, in order to try to leave some address space between the user's register mappings and the auto-created mappings. It should be noted that the auto-creation process will overwrite, without warning, any address space which is already in use.

MAP REAL, TIME AND DATE FIELDS AS:


Real, time and date fields are too big to map to a single 16-bit register. This pull-down menu allows the user to choose a format for such fields. Choosing 32-bit for example causes the fields to be mapped to two consecutive 16-bit registers. Selecting 16-bit or BCD format truncates the data.

8.2.11 AUTOCREATE (Cont.)


OK

Clicking on OK causes the software to scan the target database looking for PROGCTRL blocks. When such a block is found, three sets of (contiguous) MODBUS registers are created: PROGCTRL block registers; associated PROGCHAN block registers; and SEGMENT block registers (for segments associated with the PROGCHAN blocks).

If this process fails for any reason, a failure message appears in the report pane at the bottom of the window (not shown in the figure below).



8.3 VIEW MENU



This menu allows the user to enable/disable the display of the Toolbar, the Status bar, and the Report Window.

This menu may also be used to call:

the TCP properties display (Shortcut <Ctrl> + <D>)

The Port Properties tab page


The Register tab page

The Digital tab page

The Diagnostic tab page

The Table tab page.


8.4 HELP MENU



This menu allows:

Access to the Modbus tools Online Help file (this file).

The user to view the 'About MdbTools' display.


(shortcut: About tool )

8.4.1 About



The 'About' tool (above), or the Help menu item 'About Mdb Tools...' can be used to call this display.

Note that the details of the display depend on the version of Modbus Tools currently being used. The figure below is given for illustrative purposes only.



8.5 CONTEXT MENU


This menu, which includes the functions of the Edit menu, appears when the right-hand button on the mouse is clicked, whilst the cursor is hovering over the main Modbus tools edit area.

Undo	Ctrl+Z
Redo Delete Register	Ctrl+Y
<hr/>	
Cut	Ctrl+X
Copy	Ctrl+C
Paste	Ctrl+V
Paste Special...	Ctrl+Q
Delete	Del
<hr/>	
Goto	Ctrl+G
<hr/>	
Add Registers	Ctrl+R
Add Table	Ctrl+T
<hr/>	
Autocreate	▶

8.5.1 Undo (last action)

Use this command to undo up to the last six editing actions (if possible). The item is 'greyed out' if there is no previous action to be 'undone'.

Other access:

'Undo' tool ,


<Ctrl> + <Z>.

Edit menu 'Undo (last action)' item.

8.5.2 Redo (last action)

Use this command to reverse the last undo action (if possible). The item is 'greyed out' if there is no previous undo action to be 'redone'.

Other access:

'Redo' tool ,

<Ctrl> + <Y>,

Edit menu 'Redo (last action)' item.

8.5.3 Cut

Deletes the current selected registers from the configuration and places them on the clipboard, ready for pasting elsewhere. The item is 'greyed out' if no registers are selected.

Other access:

'Cut' tool ,


<Ctrl> + <X>,

Edit menu 'Cut' item.

8.5.4 Copy

Copies the current selected registers to the clipboard, ready for pasting elsewhere. The original registers remain unchanged. The item is 'greyed out' if no registers are selected.

Other access:

'Copy' tool ,


<Ctrl> + <C>,

Edit menu 'Copy' item.

8.5.5 Paste

This inserts a copy of the clipboard contents into the document. The clipboard contents remain unchanged. The item is 'greyed out' if the clipboard is empty.

Other access:

'Paste' tool ,


<Ctrl> + <P>,

Edit menu 'Paste' item.

8.5.6 Paste Special...

This inserts a copy of the clipboard contents into a new, user definable location. The clipboard contents remain unchanged. The item is 'greyed out' if the clipboard is empty or if multiple slaves are included in the clipboard content.

Other access:

'Paste To' tool ,

<Ctrl> + <Q>,

Edit menu item 'Paste Special...'

8.5.7 Delete

This item deletes currently selected registers from the configuration. The item is 'greyed out' if no registers are selected. Unlike the 'Cut' command, deleted registers are not placed on the clipboard and cannot thus be 'pasted'.

Other access:

<Delete> key,

Edit menu item 'Delete'.

8.5.8 Goto

From the 'Tables tab', this command moves the user to the Register tab or Digital tab which contains the highlighted table, and highlights the first register assigned to that table.

From the Register tab or Digital tab, the command moves the user to the 'Tables tab' and selects the table that the selected register is assigned to.

If multiple registers are selected, then the table associated with the first of the selected registers is moved to. If the register is not assigned to a table, no navigation takes place.

The item is 'greyed out' if no registers are selected.

Other access:

<Ctrl> + <G>.

Edit menu 'Goto' item.

8.5.9 Add Registers

This is used to add registers to the table configuration, as described in 'Adding Registers'.

Shortcut:

'Add registers' tool 

8.5.10 Add Table

This command is not available in 'Auto create tables' mode.

All selected 'unassigned' registers are placed into a new table by this command.

Assigned registers are ignored.

Only those registers associated with the same slave as the first unassigned register will be included in the new table.


This command is greyed out if there are no selected, unassigned registers.

Other access:

<Ctrl> + <T>

Edit menu 'Add Table' item.


8.5.11 Autocreate



This allows the user to map programmer block fields to MODBUS registers automatically. This feature applies only to MODBUS slave devices which support PROGCHAN blocks; the selection being disabled for other devices and for Profibus communications.

When clicked on, a dialogue box opens, as shown below.

8.5.11 AUTOCREATE (Cont.)



STARTING ADDRESS FOR NEW REGISTERS:

Allows the user to choose an address at which to start creating new registers. This is set by default to 10000, in order to try to leave some address space between the user's register mappings and the auto-created mappings. It should be noted that the auto-creation process will overwrite, without warning, any address space which is already in use.


MAP REAL, TIME AND DATE FIELDS AS:

Real, time and date fields are too big to map to a single 16-bit register. This pull-down menu allows the user to choose a format for such fields. Choosing 32-bit for example causes the fields to be mapped to two consecutive 16-bit registers. Selecting 16-bit or BCD format truncates the data.

OK

Clicking on OK causes the software to scan the target database looking for PROGCTRL blocks. When such a block is found, three sets of (contiguous) MODBUS registers are created: PROGCTRL block registers; associated PROGCHAN block registers; and SEGMENT block registers (for segments associated with the PROGCHAN blocks).

If this process fails for any reason, a failure message appears in the report pane at the bottom of the window (not shown in the figure below).



9 COMMAND LINE PARAMETERS

MdbTools can also be operated using Command Line parameters.

The following image indicates the parameters that can be configured using the Command line prompt. All parameters are single space separated and are case insensitive.



Note:

This graphic is displayed using the /Help Command line parameter, it shows ALL command line parameters.

9.1 MDBTOOLS [/ <COMMAND>] <PATH> [/ CSVDELIMITER:] COMMAND LINE PARAMETER

This Command line parameter will create a .csv file from the specified file on the defined path.

If the path specifies a file, then it must be of type .ujg, .gwf or .csv file.

Note

If a file type is not specified, the .ujg file is used.

If the path is to a folder then the MdbTools retrieves the default .dbf name from the ufolder.ini file, and then opens a corresponding .ujg file.

9.1.1 Example

MdbTools/Edit C:/../T2550.dbf/CsvDelimiter:

9.2 / EDIT < PATH > COMMAND LINE PARAMETER

This Command line parameter runs Modbus Tools and loads the specified .ujg, .gwf or .csv file on the defined path.

Note

Typing the filename has the same effect.

9.2.1 Example

/Edit C:/../T2550.ujg

9.3 / CREATEGWF < PATH > COMMAND LINE PARAMETER

This Command line parameter creates a .gwf file from the specified file on the defined path.

9.3.1 Example

/CreateGWF C:/../T2550.ujg

9.4 / CREATEUJG < PATH > COMMAND LINE PARAMETER

This Command line parameter creates a .ujg file from the specified file on the defined path.

9.4.1 Example

```
/CreateUJG C:/...../T2550.gwf
```

9.5 / CREATECSV < PATH > COMMAND LINE PARAMETER

This Command line parameter creates a .csv file from the specified file on the defined path.

9.5.1 Example

```
/CreateCSV C:/.../T2550.ujg
```

9.6 / CSVDELIMITER: COMMAND LINE PARAMETER

This Command line parameter loads or saves the specified .csv file on the defined path.

Note

The text following the colon (:) defines the delimiter. This can be only, COMMA, TAB, or SPACE.

9.6.1 Example

```
/CsvDelimiter:COMMA
```

9.7 / VALIDATE < PATH > COMMAND LINE PARAMETER

This Command line parameter validates the specified .ujg, .gwf or .csv file on the defined path.

9.7.1 Example

```
/Validate C:/.../T2550.gwf
```

9.8 /REGSERVER COMMAND LINE PARAMETER

This Command line parameter enters Modbus Tools registry data to allow the user to open the Modbus files.

Note:

This Command line parameter should be used with discretion, as the correct information will have been configured when the software was installed.

9.8.1 Example

```
Mdbtools /RegServer
```

9.9 /UNREGSERVER COMMAND LINE PARAMETER

This Command line parameter will remove Modbus Tools registry and will stop the user from opening Modbus files.

9.9.1 Example

```
Mdbtools /UnRegServer
```

10 OTHER ITEMS

10.1 32-BIT DATE AND TIME

The Date and Time values can be mapped within the constraints of either POSIX or ISO8601 formats.

10.1.1 POSIX format

This format maps both values into a single 32-bit number. The values are converted into the total number of seconds elapsed since midnight on January 1st 1970. When using this format, the time value is specified in the 'Field' column of the Modbus Tools.

The rules for deriving these values are as follows:

If the referenced field is in the Configuration (header) block, the Modbus table maps directly to the instrument's Real-Time Clock completely by-passing the LIN Database.

Note

All LIN Configuration (header) blocks have a TIME field, although not all have a DATE field.

For all other function blocks, the DATE field is found immediately preceding the TIME field.

Note

Invalid mapping is caused if the DATE field is not found immediately preceding the TIME field. The Modbus register will read as zero and will ignore all further write instructions.

This format supports Modbus mapping from

instruments own header block, including a T100 header block which does not have a date field

any cached header blocks, excluding a cached T100 header block

Date and Time values in BAT_CTRL block and SPP_CTRL block

Note

It also correctly rejects those TIME fields used for other purposes in SPP_CTRL block, SPP_RAMP block, and various DCM blocks as 'not time-of-day'. It does NOT support the TIMEDATE block.

10.1.2 ISO8601 format

The ISO8601 format may be used to represent either a Date or Time value.

A Date value is represented as a decimal number in the format YYYYMMDD. e.g. 14th November 2005 is represented as a decimal number, 20051114, and converted to a 32-bit hex value, 0131F4AA.

A Time value is represented as a decimal number in the format HHMMSS, e.g. 14:02:35 (2 minutes and 35 seconds past 2pm) is represented as the decimal number, 140235, and converted to a 32-bit hex value, 000223CB.

10.2 CNOMO REGISTERS

Certain instrument types have the ability to respond to specific CNOMO registers (LIN Modbus Capabilities CNOMO Response).

The CNOMO registers apply to specific data that can be read at pre-defined offsets namely Manufacturer's identity (121), Device type (122), Device Version (123) and a further register Device Heartbeat (124) reserved for future use.

If an instrument is capable of a CNOMO response, then this can be enabled via the check-box on the Auto-create panel of the Port Properties tab.

If CNOMO response is enabled then the user will be prevented from using registers in the CNOMO range, 121-124. If a user adds registers that span these locations then those registers will be reserved as read-only for CNOMO use and can not be re-assigned by the user.

If an attempt is made to add 32-bit registers that overlap with the CNOMO offsets then 16-bit registers will be inserted alongside the CNOMO registers to maintain even boundary alignment of 32-bit registers.

120		16 Bit	0	M←\$	4	
121		16 Bit	0	M←\$	4	Reserved CNOMO register: Manufacturer's ID
122		16 Bit	0	M←\$	4	Reserved CNOMO register: Device type
123		16 Bit	0	M←\$	4	Reserved CNOMO register: Device Version
124		16 Bit	0	M←\$	4	Reserved CNOMO register: (for future use)
125		16 Bit	0	M←\$	4	

11 INDEX

.dbf.....	12	Diagnostic Tab	37
.ujg	15	Diagnostic Table	24, 37, 38
.upg.....	12	Digital register data types.....	31
.uxm	17, 18	Digital Tab.....	35
/ CreateCSV < path > Command line parameter	59	Drop down menus	13
/ CreateGWF < path > Command line parameter...	58	Edit Menu.....	50, 54
/ CreateUJG < filepath > Command line parameter	59	Editing Techniques.....	13
/ CSVDelimiter		EIA232	8
Command line parameter.....	59	Exception Responses	38, 40, 41
/ CSVDelimiter	59	Export CSV	45
/ Edit < path > Command line parameter.....	58	Field.....	11, 12, 13, 15, 23, 27, 31, 33, 36, 41, 45
/ Validate < path > Command line parameter.....	59	File Menu	45
32 bit IEEE format	8	File Name	14, 15, 45
32-bit Date and Time	60	Files.....	8, 11, 12, 15, 17, 18, 24, 45, 54
About.....	11, 54	Format.....	8, 27, 30, 32, 36, 45
Add registers	11, 50, 54	Free.....	24
Add Table.....	50, 54	Function Codes.....	38, 41, 42, 43
Adding Registers.....	11, 27	Goto.....	50, 54
Analogue register data types	31	GWF Size.....	24
Async connect poll timeout.....	18	GWF Tables	24
Async connect timeout.....	18	Header block.....	60
Autocreate	50, 56	Help	11, 54
Auto-Create Tables.....	24, 27, 34	Help menu	54
BAT_CTRL block.....	60	Host resolution retry delay.....	18
CNOMO Response	24	Import CSV	45
Combo menus.....	13	Instr No.....	17, 30
Command Line parameters	58	Instrument Options	20
Communications interface.....	15	IP Address	17, 18
Connect initial delay.....	18	Italics	30
Connect retry 1 delay	18	Items displayed in italics	30
Connect retry 2 delay	18	Items in red	12
Connect retry 3 delay	18	LIN block	11, 31, 45
Context menu	54	LIN instrument Modbus Capabilities.....	8
Conventions.....	9	Max	8, 24, 38
Copy.....	11, 29, 45, 50, 54	Max Size.....	8, 24
Count.....	24, 27, 38, 42	MdbTools	
Cut.....	11, 15, 29, 50, 54	MdbTools [/ <command>] <filepath> [/	
data details.....	27	CsvDelimiter] Command line parameter	58
Database	8, 11, 12, 14, 15, 24, 31, 37, 38, 39, 40, 45	MdbTools	58
Decimal Places	32, 33	Menu Bar.....	44
Delete	9, 11, 13, 29, 50, 54	Modbus GateWay file	
Description.....	12, 34, 43	GWF Size.....	8, 12, 24
Desription.....	34	GWF Tables	8
Diagnostic Function Codes	41	Modbus GateWay file.....	8

Modbus GateWay file.....	12	Scan Count.....	42
Modbus GateWay file.....	24	Serial.....	8, 15, 20, 39, 40
Mode..	8, 12, 15, 23, 24, 27, 30, 34, 37, 38, 39, 40, 42, 43, 50, 54	Serial link.....	8, 39, 40
Multiple editing	13	Serial/TCP	15
Multiple Item selection.....	13	Size.....	8, 24
Name.....	8, 11, 15, 17, 18, 31, 45	Slave Addr	
New.....	11, 17, 24, 27, 34, 42, 45, 50, 54	Slave Addr.....	15
Number.....	8, 13, 17, 18, 20, 24, 27, 32, 33, 34, 36, 37, 38, 42, 43, 45	Slave Addr.....	17
Offset.....	24, 27, 30, 32, 42	Slave Addr.....	27
Open.....	11, 17, 31, 45	Slave Addr.....	30
Operating Mode	15, 20, 27, 28, 33, 38	Slave No.....	30
Overview of MDBtools.....	7	SPP_CTRL block.....	60
Page Setup	45	SPP_RAMP block.....	60
Paste	11, 29, 50, 54	Starting Address for new registers	
Paste Special.....	11, 29, 50, 54	Status Bar	12
Paste to	11, 50, 54	Table.....	8, 11, 12, 17, 24, 27, 30, 34, 36, 37, 38, 39, 40, 41, 42, 43, 45, 50, 54
Port	14, 15, 17, 20, 45	Tables Tab.....	37, 42, 43
Port Properties Tab.....	14	TCP.....	8, 11, 15, 17, 18, 20, 27, 30
Port Selection.....	23	TCP Properties	11, 17, 18
Previous configurations	45	Text/Numeric Entry	13
Print	11, 45	Tick Rate.....	34
Print Preview.....	45	Tick Rates	8, 13, 24, 34
Properties Tab.....	18	Time out	15, 38, 40, 41
Read-Write	27, 28, 33	TIMEDATE block.....	60
Reconnect num retries	18	Tool Bar	11
Reconnect retry delay.....	18	Undo.....	11, 50, 54
Red items.....	12	Unmapped Registers	30, 31
Redo	11, 50, 54	Validation checks	12
Register Tab.....	26	View.....	10, 24, 30, 37, 45, 53, 54
Report Window.....	10, 12, 42	View menu	53
Save.....	11, 12, 30, 45	What is a CNOMO register?	25
Save As.....	11, 45	Width.....	35, 36

International sales and service

Invensys Operations Management

5604 Granite Parkway, Suit 1000
Plano
Texas 75024
469-365-6400

Invensys Canada - Ontario

Invensys Operations Management
5050 South Service Road
Suite 200
Burlington ON L7L 5Y7
Canada
1-905-333-1311

Invensys Canada - Montreal

Invensys Operations Management
4 Lake Road
Dollard-des-Ormeaux
Quebec H9B 3H9
Canada
1-514-421-4210
Tel: +9714 8074700
Fax: +9714 807477

Latin America

Invensys Systems Argentina
Nuñez 4334
(1430) Buenos Aires
Argentina
Tel: +54-11-6345-2100

Middle East

Jebel Ali Free Zone
P.O. Box 61495
Dubai
United Arab Emirates
Tel: +9714 8074700
Fax: +9714 807477

Asia Pacific

IPS (S) Pte Ltd
15 Changi Business Park Central
Singapore 486057
Tel: +65 6829 8888
Fax: +65 6829 8401

Europe and Africa

Invensys Systems France
S.A.10
Avenue du Centaure B.P. 8255 Cergy
95801 Cergy Pontoise Cedex
France
Tel: +33 1 34 43 25 25
Fax: +33 1 34 43 25 00

United Kingdom - Worthing

Invensys Eurotherm Ltd
Tel: +44 1903 268500
Fax: +44 1903 265982
Email: info.uk@eurotherm.com
www.eurotherm.co.uk

© Copyright Invensys Systems, Inc. 2011

ArchestrA, Eurotherm, the Invensys Wonderware logo, EurothermSuite, Eycon, EurothermSuite, Invensys, InTouch, Wonderware and Wonderware Logger are trademarks of Invensys plc, its subsidiaries and affiliates. All other brands may be trademarks of their respective owners.

All rights are strictly reserved. No part of this document may be reproduced, modified or transmitted in any form by any means, neither may it be stored in a retrieval system other than for the purpose to act as an aid in operating the equipment to which the document relates, without the prior written permission of Invensys Eurotherm Limited.

Invensys Systems, Inc pursues a policy of continuous development and product improvement. The specifications in this document may therefore be changed without notice. The information in this document is given in good faith, but is intended for guidance only. Invensys Systems, Inc will accept no responsibility for any losses arising from errors in this document.

invensys
Foxboro