
1.	X26 TEMPERATURE AND HUMIDITY CONTROLLER	2
1.1	INTRODUCTION	2
1.1.1	Related Handbooks	2
1.1.2	Identifying the Controller	2
1.2	INSTALLATION	3
1.3	ELECTRICAL CONNECTIONS	3
1.4	CONTROL BLOCK DIAGRAM	5
1.5	TEMPERATURE AND HUMIDITY SCREENS	5
1.5.1	Operator Buttons	6
1.5.2	To Change the Temperature/Humidity Setpoint	7
1.5.3	To Select AUTO or MANUAL Mode	7
1.5.4	To Access Temperature Parameters	7
1.5.5	To Access Humidity Parameters	8
1.6	OPERATOR MENUS	9
1.6.1	To Select Different Access Levels	9
1.6.2	Navigation Diagram	10
1.7	TEMPERATURE/HUMIDITY SETPOINT PROGRAMMER	11
1.7.1	To Create or Edit a Program	12
1.7.2	To Set Up Each Segment of a Program	15
1.7.3	To Select, Run, Hold or Reset a Program	17
1.7.4	To View and Edit A Running Program	18
1.7.5	Programmer Run Parameters	19
1.8	AUTOTUNE	21
1.8.1	To Autotune the Temperature Loop	21
1.9	CONFIGURATION EXAMPLE	22
1.9.1	To Configure The Temperature Input Type	22
1.10	ORDERING CODE	23

1. X26 Temperature and Humidity Controller

1.1 INTRODUCTION


The X26 has been designed for the control of temperature and humidity in Environmental Chambers. The humidity measurement can be derived from wet and dry bulb inputs or taken directly from a humidity probe. The temperature and humidity can be programmed as functions of time using the in-built setpoint programmer. Program holdback is available to guarantee soak time at temperature and humidity. Six sets of PID parameters can be programmed to give accurate control under varying combinations of temperature and humidity. Two user programmable event outputs are also available to activate external devices - such as vibration test equipment. Up to 50 setpoint programs can be stored in the X26. Each can be assigned a customer defined name.

A real time clock can be set to start and stop programs at defined times of the day and week.

Boost heating and cooling outputs are provided. Cooling by-pass and compressor minimum on-time outputs are also provided.

Modbus digital communications is available for connection to supervisory computers or Programmable Logic Controllers.

1.1.1 Related Handbooks

For further details not described in this supplement please refer to the following handbooks where this symbol is shown :-

- 2604 Engineering Handbook, part no. HA026761 issue 3.0.
- 2604 Installation and Operation Handbook Part No. HA026491

1.1.2 Identifying the Controller

The controller type is identified by a label fixed to the side of the case. This label contains the order code which may vary from controller to controller.

The order code for your controller can be checked from the explanation given at the end of this supplement.

1.2 INSTALLATION

The X26 controller should be installed as described in Chapter 2 of the Installation and Operation Handbook.

WARNING

You must ensure that the controller is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct. See 2704 Engineering Handbook for details.



1.3 ELECTRICAL CONNECTIONS

Before proceeding further, please read Appendix B, Safety and EMC information, in the above handbooks.

The X26 has one temperature and one humidity control loop with up to 50 programs and 500 segments in total.

The input and output slots will have been populated with modules in accordance with the ordering code.






Figure 1-1: Electrical Connections

1.4 CONTROL BLOCK DIAGRAM




1.5 TEMPERATURE AND HUMIDITY SCREENS

Switch on the controller. After a brief self-test sequence, during which the controller displays the software version number, you will see an overview display for the Temperature loop.

Two overviews are available one for temperature and the second for humidity. Press the middle  button to step between the two screens.

LP1' will light when the temperature screen has been selected and 'LP2' when the humidity screen has been selected.


The top parameter is the measured temperature or humidity. The middle parameter is the target setpoint. The bottom 'text panel' shows an output bar graph. The bar graph is split with the centre representing zero output. A right-hand bar indicates heating/humidify demand, a left-hand bar cooling/dehumidify demand.



- ← Measured Temperature
- ← Temperature Setpoint
(or Target Output in Manual Mode)
- ← Heat/Cool output bar graph.

The bar graph is split with the centre representing zero output.
A right-hand bar indicates heating demand
A left-hand bar cooling demand.

Press  to step between Temperature and Humidity overviews



- ← Measured Humidity
- ← Humidity Setpoint
(or Target Output in Manual Mode)
- ← Hum/Dehum output bar graph.


The bar graph is split with the centre representing zero output.
A right-hand bar indicates humidify demand
A left-hand bar dehumidify demand.








Figure 1-2: Temperature and Humidity Overview Displays

Note: When the controller is first switched on, it will be in Operator Level 1. To select different levels of operation refer to section 1.6.




1.5.1 Operator Buttons



This is a summary of the Operator Buttons





	<p>Auto/Manual button</p>	<p>When pressed, this toggles between automatic and manual mode:</p> <ul style="list-style-type: none"> ▪ If the controller is in automatic mode 'AUTO' is displayed ▪ If the controller is in manual mode, 'MAN' is displayed
	<p>Loop select button</p>	<p>Each press selects a different overview display</p>
	<p>Programmer button</p>	<ul style="list-style-type: none"> • Press once to RUN a program. 'RUN' will be displayed • Press again to HOLD a program. 'HOLD' will be displayed • Press again to toggle between RUN & HOLD • Press and hold for two seconds to reset. Neither RUN or HOLD indicators are on.
	<p>Page button</p>	<p>Press to select the Page Header 'Menu'.</p>
	<p>Scroll button</p>	<p>Press to select a new parameter from the page heading. If held down it will continuously scroll through the parameters.</p>
	<p>Down button</p>	<p>Press to decrease an analogue value, or to change the state of a digital value</p>
	<p>Up button</p>	<p>Press to increase an analogue value, or to change the state of a digital value</p>



1.5.2 To Change the Temperature/Humidity Setpoint

From the TEMPERATURE overview, press  or . The lower bar graph display changes to .



Press  or , to raise or lower the value. The value is accepted after a 2second delay. The humidity setpoint is changed in the same way from the Humidity overview.


1.5.3 To Select AUTO or MANUAL Mode



Press   to switch between AUTO and MANUAL


The ‘MAN’ beacon will light in manual mode and the ‘AUTO’ beacon in automatic mode. In manual mode press the  or  buttons to adjust the output demand. The physical output is updated as the value is changed in the display.



1.5.4 To Access Temperature Parameters


From the TEMPERATURE overview press . The following list of parameters is shown after each press of .

: Temperature SP
◆ 20.0


To change the temperature setpoint press  or . ◆ signifies that the parameter value may be altered

: Temperature OP
[%] 18.0


To change the temperature output press  or . ◆ will only be displayed in Manual mode

: Boost Heat SP
[%] ◆ 45

Boost Heat allows additional power to be applied. It is switched on when the % output value exceeds the Boost Heat SP for more than 10 seconds.

: Boost Heat Sta
Off


Read only display showing the status of the boost heat – On or Off

: Boost Cool SP
◆ -30.0

Boost Cool allows additional cooling to be applied. It is switched on when the % output value exceeds the Boost Cool SP for more than 10 seconds.




: Boost Cool Sta
OFF


Read only display showing the status of the boost cool – On or Off

: Temp PID set
◆ Temp PID 1

Temperature PID parameter set 1 to 6











In Access Level 2* the following three parameters are available:-


 : Low SP Limit ◆ -100.0	Temperature low setpoint limit
 : High SP Limit ◆ 200.0	Temperature high setpoint limit
 : High Temp Alarm ◆ 100.0	Temperature high alarm setpoint

Press middle  button to return to the TEMPERATURE overview

1.5.5 To Access Humidity Parameters

Press . The following list of parameters is shown after each press of .

 : Humidity SP ◆ 70.0	To change the humidity setpoint press  or  . ◆ signifies that the parameter value may be altered
 : Humidity OP [%] 14.0	To change the humidity output press  or  . ◆ will only be displayed in Manual mode
 : Hum'ty PID set ◆ Hum'ty PID 1	Humidity PID parameter set 1 to 6
 : Cool By-pass On	The cooling by-pass turns on when neither cooling or dehumidification is demanded
 : Compressor OP Off	Compressor output status
 : Comp min time ◆ 0:00:30.0	Compressor minimum time sets the minimum time that the compressor will remain on. This parameter is only available in Access level 2*

Press middle  button to return to the HUMIDITY overview

* To select Access level 2 see section 1.6.1.

1.6 OPERATOR MENUS

Three levels of access are provided.







Level 1 is for normal running of the process and provides menu's to run a program and to edit a program.

Level 2 provides access to the high and low temperature setpoint limits, the high temperature alarm setpoint and the compressor minimum on-time.

Level 3 is for commissioning the controller. It provides additional menu's to set-up the temperature and humidity control parameters and to automatically tune the loops.


1.6.1 To Select Different Access Levels

From the 'ACCESS' menu header

1. Press  to display 'Access Level'
2. Press  or  to select the level required
3. Press  to display 'Enter Passcode'. The defaults are 2 for Level 2; 3 for Level 3 and 4 for configuration level
4. Press  or  to enter the passcode. If the correct passcode is entered the controller will now operate in that level.

Further information is available in the Engineering Handbook.

1.6.2 Navigation Diagram



1.7 TEMPERATURE/HUMIDITY SETPOINT PROGRAMMER

The programmer has two setpoint profiles for temperature and humidity. Digital inputs are available for Run, Reset and Hold. Two digital event outputs are configured which may be wired to operate external devices.

Up to 50 programs can be stored.








































Figure 1-3: Temperature/Humidity Program

1.7.1 To Create or Edit a Program

- A running program cannot be edited, it must first be Reset. Temporary changes may, however, be made if the program is put into Hold. These changes only apply to the current execution of the program and will not be stored as permanent changes
- Any non-running program can be edited or created while another program is running.
- It is first necessary to set up the parameters which are common to the whole program, as follows:-

Do This	This Is The Display You Should See	Additional Notes
1. From any display press  as many times as necessary to access ' PROGRAM EDIT '	 :PROGRAM EDIT ◆ Program Page	In the notes below, text shown in <i>italics> is the factory default</i>
2. Press  to select the program to edit 3. Press  or  to select the program number	Edit Prg: ◆ 3 Program 3	Up to 50 programs can be stored. The name of the program may also be set up by the user in this page. The text 'Program 3', shown here will then display the program name
4. Press  to display ' HBk Mode ' and press  or  to select	 :HBk Mode ◆ None	Choices are:- <i>None</i> - No holdback Per Prog - applied over the whole program Per Seg - selectable in every segment
5. Press  to display ' TEMP HBk Type ' and press  or  to select	 : TEMP HBk Type ◆ Off	Holdback type for the temperature loop This parameter only appears if HBk Mode = Per Prog Fine and course holdback allows two levels of holdback to be applied to different segments. They are set as deviations between SP and PV Choices are:- <i>Off</i> Fine Lo Note 1 on page Fine Hi 1-14 describes Fine Band Holdback Course Lo Course Hi Course Band

<p>7. Press  to display 'HUMIDITY HBk Type' and press  or  to select</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> : HUMID HBk Type  Off </div>	<p>Holdback type for the humidity loop. Values are the same as for the TEMPERATURE Loop</p>
<p>8. Press  to display 'Program Cycles' and press  or  to select the number of times the program is to repeat</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> : Program Cycles  Cont </div>	<p><i>Cont</i> The program repeats continuously 1-999 To set the number of repeat cycles</p>
<p>9. Press  to display 'End Action' and press  or  to select</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> : End Action  Dwell </div>	<p>Defines the action in the end segment. Choices are:- <i>Dwell</i> - the program will dwell indefinitely at the conditions set in the end segment <i>Reset</i> - the program will reset to the start conditions</p>
<p>10. Press  to display 'Program Name'</p> <p>1. Press  or  to change the text of the flashing character</p> <p>2. Press  to select the next and subsequent characters and</p> <p>11. press  or  until the customised name is entered</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> : Program Name  Program 1 </div>	<p><i>Program 1</i> is the default name Up to 16 alpha-numeric characters can be entered</p>

Note 1 Holdback freezes the program if the process value does not track the setpoint by an amount which can be set by the user.

It may apply when:

- The PV is below the SP by a pre-set value (Fine/Coarse Lo),
- The PV is above the SP by a pre-set value(Fine/Coarse Hi)
- The PV is below or above the SP by a pre-set value (Fine/Coarse Band).

Fine and Coarse Holdback values allow you to apply one value of holdback to selected segments and another value to other segments. For example, you could apply ‘Fine Holdback’ to one or more Dwell segments and ‘Coarse Holdback’ to one or more Ramp segments

In a ‘**Ramp**’ it indicates that the process value is lagging the setpoint by more than a pre-set amount and that the program is waiting for the process to catch up.

In a ‘**Dwell**’ it will freeze the segment time if the difference between SP and PV exceeds pre-set limits.

In both cases it guarantees the correct soak period for the product.

Holdback (PROGRAM EDIT Program page) may be configured in three modes:

- OFF - holdback does not operate
- Applied to the complete program. Holdback operates the same way in every segment
- To each individual segment. A different holdback type can be applied to each segment

Example:

Holdback, operating in each segment, is often used in a temperature control application as detailed below:-

During a ramp up period the holdback type may be set to deviation low. If the Process Value lags the programmed rate of rise, holdback will stop the program until the PV catches up. This prevents the set program from entering the next segment until the PV has attained the correct temperature.















































Figure 1-4: Effect of Holdback to Produce Guaranteed soak

1.7.2 To Set Up Each Segment of a Program

Having set up the parameters which are common to the selected program, it is now necessary to set up every segment, as follows:-









Do This	This Is The Display You Should See	Additional Notes
1. From the ' PROGRAM EDIT ' header, press  or  to select ' Segment Page '		In the notes below, text shown in <i>italics</i> is the factory default
2. Press  to select the program to edit		This selects the program to be edited <i>Program x</i> ' is the default text. It will show the <i>name</i> of the program if this has been set up in the 'Program Page'
3. Press  to select ' Segment Number ' 4. Press  or  to change the segment number if required		This selects the segment number to be edited Up to 100 segments can be set up
5. Press  to select ' Segment Type ' 6. Press  or  to select the segment type		This selects the type of segment The choices are:- <i>Profile</i> - A temperature/humidity time segment End Segment - The last segment in the program (press  to confirm) Go Back - Repeat part of program Not shown for segment 1.
7. For a profile segment, press  to select ' TEMPERATURE Target ' 8. Press  or  to edit the value		This is the value which the temperature will aim for in the segment It is adjustable between Temp lo and Temp hi limits set in configuration level

<p>9. For a profile segment, press  to select 'TEMP HBk Type'</p>		<p>Holdback type for the temperature loop This parameter only appears if 'HBk Mode = Per Segment'</p>
<p>10. Press  or  to edit the value</p>		<p>This has the same settings as for the whole program</p>
<p>11. Press  to select 'HUMIDITY Target'</p>		<p>This is the value which the humidity will aim for in the segment It is adjustable between Hum lo and Hum hi limits set in configuration level</p>
<p>12. Press  or  to edit the value</p>		
<p>12. For a profile segment, press  to select 'HUM HBk Type'</p>		<p>Holdback type for the humidity loop This parameter only appears if 'HBk Mode = Per Segment'</p>
<p>13. Press  or  to edit the value</p>		<p>This has the same settings as for the whole program</p>
<p>14. Press  to select 'Segment Duration'</p>		<p>The time for which the temperature/humidity takes to reach its target value (ramp) or remains at its set value (dwell)</p>
<p>15. Press  or  to change the time</p>		<p>Set in h:m:s</p>
<p>16. Press  to select the 'Temperature PID Set'</p>		<p>This selects the PID set (1 to 6) which will operate in this segment.</p>
<p>17. Press  or  to select a set</p>		<p>The next parameter selects the PID set which will operate for the humidity loop</p>
<p>18. Press  to select 'Programmer Digital Outputs'</p>		<p>Two events are available ■ indicates that the event output will be on</p>
<p>19. Press  or  to turn the output on or off in the segment</p>		<p>□ indicates that the event output will be off. This is the factory default</p>

Repeat the above stages for each segment required in the program

1.7.3 To Select, Run, Hold or Reset a Program

Assuming programs have been created:-

Do This	This Is The Display You Should See	Additional Notes
<ol style="list-style-type: none"> From any display press  as many times as necessary to 'PROGRAM RUN' Press  to display 'Prg1: ↕ 1' Press  or  to select the program number/name 	<p>Select the program number</p> <div data-bbox="434 362 684 435" style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> :PROGRAM RUN </div> <div data-bbox="434 511 684 584" style="border: 1px solid black; padding: 5px;"> Prg: ↕ 1 Seg: 1 Program 1 </div>	<p>The last selected program number is displayed. This may be 1 to 50.</p> <p>The program number can only be changed when the program is showing Reset.</p> <p><i>Program x</i>' is the default text. It will show the <i>name</i> of the program if this has been set up in the 'Program Page'</p>
<ol style="list-style-type: none"> Press the right hand  button to Run the program. Press the right hand  button again to Hold the program Press and hold the right hand  button for at least 2 seconds to Reset the program 	<p>Run, Hold or Reset the program</p> <div data-bbox="437 680 687 754" style="border: 1px solid black; padding: 5px;"> Prg: ↕ 1 Seg: 1 Program 1 </div>	<p>This display shows the actual segment number. It will progress to further segments while the program is running.</p> <p>Other displays can be viewed while the program is running using the appropriate buttons.</p>

Notes:-

- If the digital inputs have been wired to external buttons, the programmer may be run, held or reset from these.
- In 'Hold' the programmer is frozen at its current point. In this state you can make temporary changes to program parameters such as a target setpoint, ramp rates and dwells. Such changes can only be made in the current or subsequent segments and will only remain effective until the end of the currently running segment, when they will be overwritten by the stored program values.
- In 'Reset' the programmer is inactive and the controller behaves as a standard controller, with the setpoint determined by the raise/lower buttons.
- A list of parameters available for a running program is available under the menu PROGRAM RUN.

It is possible to set the program to run at a fixed time and day of the week. See Example 1.6.6.2.











1.7.4 To View and Edit A Running Program

From time to time it may be necessary to make temporary changes to the currently running program, for example, to change the target setpoint or to add time to a segment. The current running program can only be edited under the following conditions:-

- The program must be put into **‘Hold’** or **‘Reset’**
- Changes to the currently running segment are temporary and apply only to the current run
- Permanent changes should be made in the **‘PROGRAM EDIT’** pages, see previous section.
- Other programs can be created or edited when another program is running

1.7.4.1 Example: To Change the Target Setpoint or Time












Place the program in **‘Hold’**. Then:-

Do This	This Is The Display You Should See	Additional Notes
1. From any display press  as many times as necessary to access ‘PROGRAM RUN’ page		
2. Press  to select ‘Seg Time Rem’		
3. Press  or  to increase a decrease the time remaining		
4. Press  to scroll to ‘Prog Temp SP’		
5. Press  or  to change the value		

Now place the programmer in Run











1.7.5 Programmer Run Parameters

This table lists all the parameters which are available when a program is running.

Table Number: 1.6.5.		PROGRAM RUN	
Parameter Name	Parameter Description	Notes	Default
	Program number Segment number Program name	Read only	
	Time remaining to end of segment	In 'Hold' mode these parameters can be adjusted. The changes will only be valid for the current run of the program. The stored program values will not be changed	
	Current temperature program setpoint		
	Current humidity program setpoint		
	Current program event outputs		
	Program start day Never Monday to Friday	Press  or  to set the start day and time. Set the start day to never to inhibit this function. The program will automatically start at the set time	Never
	Program start time hrs:mins:secs		
	Current day		
	Current time hrs:mins:secs		

1.7.5.1 Example: To Set Program Start Day and Start Time

With the programmer in **Reset**:-

Do This	This Is The Display You Should See	Additional Notes
<p>1. Form the 'Prog Run' menu press  to select 'Prog Start Day'</p> <p>2. Press  or  to select the day of the week</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> :Prog Start Day  Monday </div>	<p>The program will start <u>every</u> Monday.</p> <p>Once the program has started set the day back to 'Never' so that the program does not restart on the following Monday</p>
<p>3. Press  to scroll to 'Prog Start Time'</p> <p>4. Press  or  to set the start time</p>	<div style="border: 1px solid black; padding: 5px; text-align: center;"> :Prog Start Time  06:30:00 </div>	<p>The program will start <u>every</u> Monday at 06:30</p>














1.8 AUTOTUNE

In most cases it will only be necessary to carry out the Autotune procedure when commissioning your controller.

A full description of tuning is given in the Engineering Handbook.

The description below shows how to adjust the parameters for autotuning a loop.

1.8.1 To Autotune the Temperature Loop

Do This	This Is The Display You Should See	Additional Notes
<p>1. From any display press  as many times as necessary until the 'AUTOTUNE' page header is displayed</p>		<p>Autotune page is at Level 3 by default but may have been promoted to L1 or L2.</p>
<p>2. Press  to display 'Tune OL'</p> <p>3. Press  or  to set the tune low limit</p> <p>4. Repeat for 'Tune OH'</p>		<p>This sets the low and high output power limits which will apply only during the tuning process.</p>
<p>5. Press  to display 'Autotune Loop'</p> <p>6. Press  or  to select the 'TEMPERATURE' loop</p>	 	
<p>7. Press  to display the state of Autotuning</p>		<p>For further information on tuning, refer to the Installation and Operation Manual</p>

1.9 CONFIGURATION EXAMPLE











The example given here shows how to re-configure the sensor input type. This is typical of the type of parameter which may need to be changed on site and is used to illustrate the principle of configuration.

WARNING

Configuration level gives access to a wide range of parameters which match the controller to the process. Incorrect configuration could result in damage to the process being controlled and/or personal injury. It is the responsibility of the person commissioning the process to ensure that the configuration is correct.

1.9.1 To Configure The Temperature Input Type

To change thermocouple, RTD or process input type:-

Do This	This Is The Display You Should See	Additional Notes
1. Press  as many times as necessary until the 'STANDARD IO' page header is displayed		
2. Press  to display 'Channel Type' 3. Press  or  to select the type of input		Choices most applicable to this application are: RTD, Thermocouple, 40mV, 80mV, mA, Volts,
4. Press  to display 'Linearisation' 5. Press  or  to select linearisation type		Choices most applicable to this application are: PT100, Linear, J-type, K-type, T-type, L-type, N-type

Further parameters are available in the same way. Refer to the Engineering Handbook for further details

1.10 ORDERING CODE

1	X26	2	3	4	5	6	7	8	9
---	-----	---	---	---	---	---	---	---	---

2. Supply Voltage	
VH	85-264Vac
VL	20-29Vac/dc

3. Module 1 Retransmission output	
XX	Not fitted
First character	
T-	Temperature
H-	Humidity
Second character	
-Y	0-20mA
-A	4-20mA
-W	0-5Vdc
-G	1-5Vdc
-V	0-10Vdc

4. Module 3 Humidify + Dehumidify outputs	
XX	Not fitted
TP	Dual logic
RR	Dual relay
TT	Dual triac
DO	Dual 4-20mA

5. Module 4 Compressor on/off & bypass outputs	
XX	Not fitted
TT	Dual triac
RR	Dual relay
2 nd retransmission output	
-Y	4-20mA
-A	0-20mA
-W	0-5Vdc
-G	1-5Vdc
-V	0-10Vdc

6. Module 5 Heating and cooling outputs	
XX	Not fitted
TP	Dual logic
RR	Dual relay
TT	Dual triac
DO	Dual 4-20mA

7. Module 6 Wet bulb input or transmitter supply	
XX	Not fitted
PV	Wet bulb input
MS	24Vdc humidity transducer supply

8. Digital Communications	
XX	Not Fitted
Modbus	
A2	RS232
F2	4-wire RS485/422
Y2	2-wire RS485

9. Manual	
XXX	None
ENG	English
FRA	French
GER	German
SPA	Spanish

Configuration (Optional)

1	2	3	4
---	---	---	---

1 & 2. wet & dry bulb inputs		
X	Not used	
Resistance thermometer		
Z	PT100	°C Range °F
		-200 to 850 -325 to 1562
Thermocouples		
J	Type J	-210 to 1200 -340 to 2192
K	Type K	-200 to 1372 -325 to 2500
T	Type T	-200 to 400 -325 to 750
L	Type L	-200 to 900 -325 to 1650
N	Type N	-200 to 1300 -325 to 2370
Process inputs (linear)		
M	±100mV	Scaleable -1999 to 9999
Y	0-20mA	Scaleable -1999 to 9999
A	4-20mA	Scaleable -1999 to 9999
W	0-5Vdc	Scaleable -1999 to 9999
G	1-5Vdc	Scaleable -1999 to 9999
V	0-10Vdc	Scaleable -1999 to 9999

3. Units	
C	°C
F	°F

4. Humidity input	
X	NOT FITTED
N	0-1Vdc
V	0-10Vdc
Y	0-20mA
A	4-20mA
W	0-5Vdc

